TRANQUILITY® 16 (TC) SERIES





Commercial Horizontal & Vertical Packaged Water-Source Heat Pumps

SOHz-HFC-410A

INSTALLATION, OPERATION ET MAINTENANCE

97B0075N02 Revised: 24 January, 2023



Table of Contents

Model Nomenclature – General Overview	3
General Information	4
Unit Physical Data	6
Horizontal Installation	7
Field Conversion of Air Discharge	10
Horizontal Installation	11
Duct System Installation	12
Vertical Installation	13
Piping Installation	16
Water-Loop Heat Pump Applications	17
Ground-Loop Heat Pump Applications	18
Ground-Water Heat Pump Applications	20
Water Quality Standards	22
Electrical - Line Voltage	23
Electrical Data	24
Electrical - Power Wiring	25
Electrical - Power & Low Voltage Wiring	26
Electrical - Low Voltage Wiring	27
Blower Performance Data	28
ECM Motor – Blower Performance Data	30
Electrical - Thermostat Wiring	33
TC-Horizontal – Dimensional Data	34
TC-Vertical Upflow – Dimensional Data	36
TC Series Wiring Diagram Matrix	38
Controls – CXM2 and DXM2.5	39
Operating Limits	40
Piping System Cleaning and Flushing	41
Unit Starting and Operating Conditions	42
Unit Start-Up Procedure	43
Preventive Maintenance	45
Functional Troubleshooting	46
Performance Troubleshooting	47
Functional Troubleshooting - S-I Units	48
Warranty	49
Revision History	52

This Page Intentionally Left Blank

THE SMART SOLUTION FOR ENERGY EFFICIENCY

Tranquility 16 (TC) Series Rev.: 24 January, 2023



Model Nomenclature – General Overview

General Information

Saftey

Warnings, cautions, and notices appear throught this manual. Read these items carefully before attempting any installation, service, or troubeshooting of the equipment.

DANGER: Indicates an immediate hazardous situation, which if not avoided <u>will result in death or serious</u> <u>injury</u>. DANGER labels on unit access panels must be observed.

WARNING: Indicates an immediate hazardous situation, which if not avoided <u>will result in death or serious injury</u>.

CAUTION: Indicates a potentially hazardous situation or an unsafe practice, which if not avoided <u>could result</u> in minor or moderate injury with product or property damage.

NOTICE: Notification of installation, operation, or maintenance information, which is important, but which is <u>not hazard-related</u>.

🔪 WARNING! 🧍

WARNING! The EarthPure[®] Application and Service Manual should be read and understood before attempting to service refrigerant circuits with HFC-410A.

ዾ WARNING! 🦊

WARNING! To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must be serviced only by technicians who meet local, state, and federal proficiency requirements.

🚹 CAUTION! 🧍

CAUTION! To avoid equipment damage, DO NOT use these units as a source of heating or cooling during the construction process. The mechanical components and filters can quickly become clogged with construction dirt and debris, which may cause system damage and void product warranty.

🕨 WARNING! 🧍

WARNING! This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

WARNING! 🖊

WARNING! All refrigerant discharged from this unit must be recovered WITHOUT EXCEPTION. Technicians must follow industry accepted guidelines and all local, state, and federal statutes for the recovery and disposal of refrigerants. If a compressor is removed from this unit, refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, refrigerant lines of the compressor must be sealed after it is removed.

Inspection

Upon receipt of the equipment, carefully check the shipment against the bill of lading. Make sure all units have been received. Inspect the packaging of each unit, and inspect each unit for damage. Ensure that the carrier makes proper notation of any shortages or damage on all copies of the freight bill and completes a common carrier inspection report. Concealed damage not discovered during unloading must be reported to the carrier within 15 days of receipt of shipment. If not filed within 15 days, the freight company can deny the claim without recourse. Note: It is the responsibility of the purchaser to file all necessary claims with the carrier. Notify your equipment supplier of all damage within fifteen (15) days of shipment.

Storage

Equipment should be stored in its original packaging in a clean, dry area. Store units in an upright position at all times. Stack units a maximum of 3 units high.

Unit Protection

Cover units on the job site with either the original packaging or an equivalent protective covering. Cap the open ends of pipes stored on the job site. In areas where painting, plastering, and/or spraying has not been completed, all due precautions must be taken to avoid physical damage to the units and contamination by foreign material. Physical damage and contamination may prevent proper start-up and may result in costly equipment clean-up.

Examine all pipes, fittings, and valves before installing any of the system components. Remove any dirt or debris found in or on these components.

Pre-Installation

Installation, Operation, and Maintenance instructions are provided with each unit. Horizontal equipment is designed for installation above false ceiling or in a ceiling plenum. Other unit configurations are typically installed in a mechanical room. The installation site chosen should include adequate service clearance around the unit. Before unit start-up, read all manuals and become familiar with the unit and its operation. Thoroughly check the system before operation.

Prepare units for installation as follows:

- 1. Compare the electrical data on the unit nameplate with ordering and shipping information to verify that the correct unit has been shipped.
- 2. Keep the cabinet covered with the original packaging until installation is complete and all plastering, painting, etc. is finished.
- 3. Verify refrigerant tubing is free of kinks or dents and that it does not touch other unit components.
- 4. Inspect all electrical connections. Connections must be clean and tight at the terminals.
- 5. Remove any blower support packaging (water-toair units only).
- 6. Some airflow patterns are field convertible (horizontal units only). Locate the airflow conversion section of this IOM.
- 7. Locate and verify any hot water generator (HWG), hanger, or other accessory kit located in the compressor section or blower section.

General Information, Cont'd.

CAUTION!

CAUTION! All three phase scroll compressors must have direction of rotation verified at start-up. Verification is achieved by checking compressor Amp draw. Amp draw will be substantially lower compared to nameplate values. Additionally, reverse rotation results in an elevated sound level compared to correct rotation. Reverse rotation will result in compressor internal overload trip within several minutes. Verify compressor type before proceeding.

🚹 CAUTION! 🧴

CAUTION! DO NOT store or install units in corrosive environments or in locations subject to temperature or humidity extremes (e.g., attics, garages, rooftops, etc.). Corrosive conditions and high temperature or humidity can significantly reduce performance, reliability, and service life. Always move and store units in an upright position. Tilting units on their sides will cause equipment damage.

CAUTION!

CAUTION! CUT HAZARD - Failure to follow this caution may result in personal injury. Sheet metal parts may have sharp edges or burrs. Use care and wear appropriate protective clothing, safety glasses and gloves when handling parts and servicing heat pumps.

WARNING! 🧴

WARNING! Polyolester Oil, commonly known as POE oil, is a synthetic oil used in many refrigeration systems including those with HFC-410A refrigerant. POE oil, if it ever comes in contact with the polymer drain pan, may cause the drain pan to leak. The polymer drain pan should never come in contact with POE oil as system failures and property damage may result.

Unit Physical Data

Tranquility[®] 16 (TC) Series (50 Hz)

TC Series	006	009	012	015	018	024	030	036	042	048	060
Compressor (1 Each)			Rota	ry					Scroll		
Factory Charge HFC-410A - kg	0.54	0.52	0.65	0.99	1.22	1.13	1.36	1.42	1.98	2.10	2.32
ECM Fan Motor & Blower											
Fan Motor (Watts)		186			49		37	3		746	
Blower Wheel Size (Dia x W) mm	127 >	k 127	152 x 127		229	x 178		229	x 203	254 x 254	305 x 254
PSC Fan Motor & Blower											
Fan Motor Type/Speeds	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3	PSC/3
Fan Motor (Watts)	19		75	5	3	149	249			249	
Blower Wheel Size (Dia x W) mm	127 >	127 x 127 152 x 127			229 x 178	3	229 x 178	229	x 203	254 x 254	305 x 254
Water Connection Size	Water Connection Size										
FPT		1/2"			3/4					1	"
Coax Volume (liters)	0.29	0.37	0.50	0.68	0.79	0.68	1.1	3	1.83	1.54	2.32
Vertical											
Air Coil Dimensions (H x W) mm	2	54 x 381	3Row	508 x 438 3Row				610 x 553 3Row		610 x 718 3Row	
Filter Standard - 25.4mm Throwaway mm		254 x 4	57	508 x 508				610 x 610		457 x 610 356 x 610	
Weight - Operating kg	47	48	52	70	72	86	90	92	99	120	126
Weight - Packaged kg	51	52	56	72	74	88	92	95	102	123	130
Horizontal											
Air Coil Dimensions (H x W) mm	2	54 x 381	3Row		406 x 5	59 3Ro	W		508 >	k 635 3Row	
Filter Standard - 25.4mm Throwaway mm		254 x 4	57	406 :	406 x 635 4		457 x 635		508 (2)	356 x 508 508 x 610	
Weight - Operating kg	47	48	52	70	72	79	83	92	99	120	126
Weight - Packaged kg	51	52	56	72	74	81	85	95	102	123	130

Notes:

All units have dual isolation compressor mounts for quiet operation, thermal expansion valves for refrigerant metering, and 22.2mm & 28.6mm electrical knockouts to accommodate field wiring.

FPT - Female Pipe Thread

Condensate Drain Connection is rubber coupling that couples to 3/4" schedule 40/80 PVC.

Unit Maximum Water Working Pressure									
Options	Max Pressure kPa								
Base Unit	3447								

Horizontal Installation

Horizontal Unit Location

Units are not designed for outdoor installation. Locate the unit in an INDOOR area that allows enough space for service personnel to perform typical maintenance or repairs without removing unit from the ceiling. Horizontal units are typically installed above a false ceiling or in a ceiling plenum. Never install units in areas subject to freezing or where humidity levels could cause cabinet condensation (such as unconditioned spaces subject to 100% outside air). Consideration should be given to access for easy removal of the filter and access panels. Provide sufficient room to make water, electrical, and duct connection(s).

If the unit is located in a confined space, such as a closet, provisions must be made for return air to freely enter the space by means of a louvered door, etc. Any access panel screws that would be difficult to remove after the unit is installed should be removed prior to setting the unit. Refer to Figure 3 for an illustration of a typical installation. Refer to unit submittal data or engineering design guide for dimensional data.

Conform to the following guidelines when selecting unit location:

- Provide a hinged access door in concealed-spline or plaster ceilings. Provide removable ceiling tiles in T-bar or lay-in ceilings. Refer to horizontal unit dimensions for specific series and model in unit submittal data. Size the access opening to accommodate the service technician during the removal or replacement of the compressor, control, or blower assembly.
- 2. Provide access to hanger brackets, water valves and fittings. Provide screwdriver clearance to access panels, discharge collars and all electrical connections.
- 3. DO NOT obstruct the space beneath the unit with piping, electrical cables and other items that prohibit future removal of components or the unit itself.
- 4. Use a manual portable jack/lift to lift and support the weight of the unit during installation and servicing.

The installation of water source heat pump units and all associated components, parts and accessories which make up the installation shall be in accordance with the regulations of ALL authorities having jurisdiction and MUST conform to all applicable codes. It is the responsibility of the installing contractor to determine and comply with ALL applicable codes and regulations.

Mounting Horizontal Units

Horizontal units have 4 hanger brackets partially attached at the factory, one at each corner. Enclosed within the unit there is a hanger kit hardware bag containing vibration isolation grommets, washers, screws and a hanger installation instruction page. One additional screw from the hardware bag must be added to each hanger bracket before unit installation.Tighten each screw to 75 in-lbs (8.5 Nm). See Figure 1. Refer to the hanger installation instruction page contained in the hardware bag for details of final hanger bracket attachment and unit suspension. See Figure 1a.

Use four (4) field supplied threaded rods and factory provided vibration isolators to suspend the unit. Safely lift the unit into position supporting the bottom of the unit. Ensure the top of the unit is not in contact with any external objects. Connect the top end of the 4 all-thread rods, slide rods through the brackets and grommet then assemble washers and double nuts at each rod. Ensure that the unit is approximately level and that the threaded rod extends past the nuts.

Pitch the unit toward the drain as shown in Figure 2 to improve the condensate drainage. On small units (less than 8.8 kW) ensure that unit pitch does not cause condensate leaks inside the cabinet.

Figure 1: Hanger Bracket



Figure 1a:



Horizontal Installation, Cont'd.

Figure 2: Horizontal Unit Pitch



Figure 3: Typical Horizontal Unit Installation



Air Coil - To obtain maximum performance, the air coil should be cleaned before start-up. A 10% solution of dishwasher detergent and water is recommended for both sides of the coil. A thorough water rinse should follow. UV based anti-bacterial systems may damage coated air coils.

Notice! Installation Note - Ducted Return: Many horizontal WSHPs are installed in a return air ceiling plenum application (above ceiling). Vertical WSHPs are commonly installed in a mechanical room with free return (e.g. louvered door). Therefore, filter rails are the industry standard and are included on ClimateMaster commercial heat pumps for the purposes of holding the filter only. For ducted return applications, the filter rail must be removed and replaced with a duct flange or filter frame. Canvas or flexible connectors should also be used to minimize vibration between the unit and ductwork.

Horizontal Installation, Cont'd.







Right Return Straight Discharge

Right Return Back Discharge





= mandatory 61 cm service access

Notes:

- 1. While clear access to all removable panels is not required, installer should take care to comply with all building codes and allow adequate clearance for future field service.
- 2. CCP and BSP requires 61 cm service access.
- 3. Blower service access is through back panel on straight discharge units or through panel opposite air coil on back discharge units.
- 4. ASP are removable panels that provide additional access to the units interior. Clear access to ASP panels is not required and they are not to be used in place of the mandatory CCP and BSP panels.

Legend:

- CCP = Control/Compressor Access Panel
- BSP = Blower Service Panel
- ASP = Additional Service Panel (not required)

Field Conversion of Air Discharge

Overview - Horizontal units can be field converted between straight (side) and back (end) discharge using the instructions below.

Note: It is not possible to field convert return air between left or right return models due to the necessity of refrigeration copper piping changes.

Preparation - Field conversion must be completed on the ground. If the unit is already hung it should be taken down for the field conversion. Place in a welllighted area. Conversion should only be attempted by a qualified service technician.

Side to Back Discharge Conversion

- 1. Remove back panel and side access panel
- 2. Loosen 2 motor slide nuts, raise motor slide assembly and remove belt and motor sheave.
- 3. Remove blower sheave. Remove motor bolts and carefully remove motor.
- 4. Remove 2 motor clips and reattach to opposite side.
- 5. Unbolt (3 per side) complete housing assembly.
- Rotate complete assembly into new position. Locate over mounting holes in base, reattach using 3 bolts per side.
- 7. Mount motor, motor sheave, blower sheave and belt. Make sure wires are not pinched and not over sharp edges. Adjust motor downward to tighten belt. Raise or lower motor slide assembly with adjusting bolt and retighten 2 slide nuts. Check for correct tension (See Tensioning V-Belt Drives page). Rewire motor (at contactor) for correct rotation. Spin blower wheel to ensure wheel is not obstructed.
- 8. Replace 2 panels.

Back to Side Discharge Conversion - If the discharge is changed from back to side, use above instruction noting that illustrations will be reversed.

Left vs. Right Return - It is not possible to field convert return air between left or right return models due to the necessity of refrigeration copper piping changes. However, the conversion process of side to back or back to side discharge for either right or left return configuration is the same. In some cases, it may be possible to rotate the entire unit 180 degrees if the return air connection needs to be on the opposite side. Note that rotating the unit will move the piping to the other end of the unit.

Figure 4: Left Return Side to Back







Rotate



Figure 5: Right Return Side to Back



Horizontal Installation

Condensate Piping - Horizontal Units - A condensate drain line must be installed and pitched away for the unit to allow for proper drainage. This connection must meet all local plumbing/building codes.

Pitch the unit toward the drain as shown in Figure 2 to improve the condensate drainage. On small units (less than 8.8 kW), ensure that unit pitch does not cause condensate leaks inside the cabinet.

Install condensate trap at each unit with the top of the trap positioned below the unit condensate drain connection as shown in Figure 6. Design the depth of the trap (water-seal) based upon the amount of ESP capability of the blower (where 51mm of ESP capability requires 51mm of trap depth). As a general rule, 38mm trap depth is the minimum.

Each unit must be installed with its own individual trap and connection to the condensate line (main) or riser. Provide a means to flush or blow out the condensate line. DO NOT install units with a common trap and/or vent.

Always vent the condensate line when dirt or air can collect in the line or a long horizontal drain line is required. Also vent when large units are working against higher external static pressure than other units connected to the same condensate main since this may cause poor drainage for all units on the line. WHEN A VENT IS INSTALLED IN THE DRAIN LINE, IT MUST BE LOCATED AFTER THE TRAP IN THE DIRECTION OF THE CONDENSATE FLOW.

Condensate drain connection is a rubber coupling that couples to 3/4" schedule 40/80 PVC. Use hose clamps to secure the pipe inside the coupling. If the connection is not secure, the connection may leak. Instructions for coupling the condensate drain to the trap are included in the bag that includes the coupling and hose clamps.

Figure 6: Horizontal Condensate Connection



CAUTION! 🧍

CAUTION! Ensure condensate line is pitched toward drain 21mm per m of run.

Duct System Installation

Duct System Installation - Proper duct sizing and design is critical to the performance of the unit. The duct system should be designed to allow adequate and even airflow through the unit during operation. Air flow through the unit MUST be at or above the minimum stated airflow for the unit to avoid equipment damage. Duct systems should be designed for quiet operation. Refer to Figure 3 for horizontal duct system details or Figure 8 for vertical duct system details. A flexible connector is recommended for both discharge and return air duct connections on metal duct systems to eliminate the transfer of vibration to the duct system. To maximize sound attenuation of the unit blower, the supply and return plenums should include internal fiberglass duct liner or be constructed from ductboard for the first few feet. Application of the unit to uninsulated ductwork in an unconditioned space is not recommended, as the unit's performance may be adversely affected.

At least one 90° elbow should be included in the supply duct to reduce air noise. If air noise or excessive air flow is a problem, the blower speed can be changed. For airflow charts, consult submittal data for the series and model of the specific unit.

If the unit is connected to existing ductwork, a previous check should have been made to ensure that the ductwork has the capacity to handle the airflow required for the unit. If ducting is too small, as in the replacement of a heating only system, larger ductwork should be installed. All existing ductwork should be checked for leaks and repaired as necessary.

THE SMART SOLUTION FOR ENERGY EFFICIENCY

Tranquility 16 (TC) Series Rev.: 24 January, 2023

Vertical Installation

Vertical Unit Location

Units are not designed for outdoor installation. Locate the unit in an INDOOR area that allows enough space for service personnel to perform typical maintenance or repairs without removing unit from the mechanical room/closet. Vertical units are typically installed in a mechanical room or closet. Never install units in areas subject to freezing or where humidity levels could cause cabinet condensation (such as unconditioned spaces subject to 100% outside air). Consideration should be given to access for easy removal of the filter and access panels. Provide sufficient room to make water, electrical, and duct connection(s).

If the unit is located in a confined space, such as a closet, provisions must be made for return air to freely enter the space by means of a louvered door, etc. Any access panel screws that would be difficult to remove after the unit is installed should be removed prior to setting the unit. Refer to Figures 7 and 8 for typical installation illustrations. Refer to unit submittal data or engineering design guide for dimensional data.

- Install the unit on a piece of rubber, neoprene or other mounting pad material for sound isolation. The pad should be at least 10mm to 13mm in thickness. Extend the pad beyond all four edges of the unit.
- 2. Provide adequate clearance for filter replacement and drain pan cleaning. Do not block filter access with piping, conduit or other materials. Refer to unit submittal data or engineering design guide for dimensional data.
- 3. Provide access for fan and fan motor maintenance and for servicing the compressor and coils without removing the unit.
- 4. Provide an unobstructed path to the unit within the closet or mechanical room. Space should be sufficient to allow removal of the unit, if necessary.
- 5. In limited side access installations, pre-removal of the control box side mounting screws will allow control box removal for future servicing (TC units only).
- 6. Provide access to water valves and fittings and screwdriver access to the unit side panels, discharge collar and all electrical connections.



Figure 8: Typical Vertical Unit Installation Using Ducted Return Air



Internally insulate supply duct for first 1.2 m each way to reduce noise

Use turning vanes in supply transition

Flexible canvas duct connector to reduce noise and vibration

Remove supply duct flanges from inside blower compartment and install on supply air opening of unit. Do not use a supply air plenum/duct smaller than the size of the supply duct flanges.



Rounded return transition

Internally insulate return transition duct to reduce noise

Vertical Installation, Cont'd.

Left Return



Right Return





Reco	Recommended Minimum Installation Clearances for Vertical Units*								
2.5	Back of unit								
cm	Side opposite return air								
15.2 cm	Front if hard piped								
Return Air Side									
	Ducted return								
2.5	- ‡ Add for duct width								
cm	- † Add 5.0 cm for 2.5 cm filter frame/rail or 7.6 cm for 5.0 cm filter frame/rail								
	Free (open) return - calculate required dimension for a maximum velocity of 3.0 m/s								

*Field installed accessories (hoses, air cleaners, etc.) may require additional space. Top supply air is shown, the same clearances apply to bottom supply air units.

Notes:

- 1. While clear access to all removable panels is not required, installer should take care to comply with all building codes and allow adequate clearance for future field service.
- Front & Side access is preferred for service access. However, all components may be serviced from the front access panel if side access is not available. (Except on units with front return air).
- 3. ASP are removable panels that provide additional access to the units interior. Clear access to ASP panels is not required and they are not to be used in place of the mandatory CCP and BSP panels.
- 4. Top supply air is shown, the same clearances apply to bottom supply air units.
- 5. Front return units (not shown) require front access for controls/compressor and left side access for blower.

Legend:

- CCP = Control/Compressor Access Panel
- BSP = Blower Service Panel
- ASP = Additional Service Panel (not required)

Vertical Installation, Cont'd.

Sound Attenuation for Vertical Units - Sound

attenuation is achieved by enclosing the unit within a small mechanical room or a closet. Additional measures for sound control include the following:

- Mount the unit so that the return air inlet is 90° to the return air grille. Refer to Figure 9. Install a sound baffle as illustrated to reduce line-of sight sound transmitted through return air grilles.
- 2. Mount the unit on a rubber or neoprene isolation pad to minimize vibration transmission to the building structure.

Figure 9: Vertical Sound Attenuation



Units with clear plastic drain lines should have regular maintenance (as required) to avoid buildup of debris, especially in new construction.

Condensate Piping for Vertical Units - A condensate line must be installed and pitched away from the unit to allow for proper drainage. This connection must meet all local plumbing/building codes. Vertical units utilize a condensate hose inside the cabinet as a trapping loop; therefore an external trap is not necessary. Figure 10a shows typical condensate connections. Figure 10b illustrates the internal trap for a typical vertical heat pump. Each unit must be installed with its own individual vent (where necessary) and a means to flush or blow out the condensate drain line. Do not install units with a common trap and/or vent.

Figure 10: Vertical Condensate Drain



Piping Installation

Installation of Supply and Return Piping

Follow these piping guidelines.

- 1. Install a drain valve at the base of each supply and return riser to facilitate system flushing.
- 2. Install shut-off / balancing valves and unions at each unit to permit unit removal for servicing.
- 3. Place strainers at the inlet of each system circulating pump.
- Select the proper hose length to allow slack between connection points. Hoses may vary in length by +2% to -4% under pressure.
- 5. Refer to Table 1. Do not exceed the minimum bend radius for the hose selected. Exceeding the minimum bend radius may cause the hose to collapse, which reduces water flow rate. Install an angle adapter to avoid sharp bends in the hose when the radius falls below the required minimum.

Insulation is not required on loop water piping except where the piping runs through unheated areas, outside the building or when the loop water temperature is below the minimum expected dew point of the pipe ambient conditions. Insulation is required if loop water temperature drops below the dew point (insulation is required for ground loop applications in most climates).

Pipe joint compound is not necessary when Teflon[®] thread tape is pre-applied to hose assemblies or when flared-end connections are used. If pipe joint compound is preferred, use compound only in small amounts on the external pipe threads of the fitting adapters. Prevent sealant from reaching the flared surfaces of the joint.

Note: When antifreeze is used in the loop, ensure that it is compatible with the Teflon tape or pipe joint compound that is applied.

Maximum allowable torque for brass fittings is 41 N-m. If a torque wrench is not available, tighten finger-tight plus one quarter turn. Tighten steel fittings as necessary.

Optional pressure-rated hose assemblies designed specifically for use with ClimateMaster units are available. Similar hoses can be obtained from alternate suppliers. Supply and return hoses are fitted with swivel-joint fittings at one end to prevent kinking during installation.

Refer to Figure 11 for an illustration of a typical supply/ return hose kit. Adapters secure hose assemblies to the unit and risers. Install hose assemblies properly and check regularly to avoid system failure and reduced service life. A backup wrench is required when tightening water connections to prevent water line damage for TC Series equipment. TS Series equipment has water connections secured to the corner post.

🕨 WARNING! 셈

WARNING! Polyolester Oil, commonly known as POE oil, is a synthetic oil used in many refrigeration systems including those with HFC-410A refrigerant. POE oil, if it ever comes in contact with PVC or CPVC piping, may cause failure of the PVC/CPVC. PVC/CPVC piping should never be used as supply or return water piping with water source heat pump products containing HFC-410A as system failures and property damage may result.

🚹 CAUTION! 🧍

CAUTION! Corrosive system water requires corrosion resistant fittings and hoses, and may require water treatment.

CAUTION!

CAUTION! Do not bend or kink supply lines or hoses.

🛕 CAUTION! 🥼

CAUTION! Piping must comply with all applicable codes.

Table 1: Metal Hose Minimum Bend Radii

Hose Diameter	Minimum Bend Radii					
12.7mm	6.4cm					
19.1mm	10.2cm					
25.4mm	14cm					
31.8mm	17.1cm					

NOTICE! Do not allow hoses to rest against structural building components. Compressor vibration may be transmitted through the hoses to the structure, causing unnecessary noise complaints.

Figure 11: Supply/Return Hose Kit



Water-Loop Heat Pump Applications

Commercial Water Loop Applications

Commercial systems typically include a number of units connected to a common piping system. Any unit plumbing maintenance work can introduce air into the piping system; therefore air elimination equipment is a major portion of the mechanical room plumbing. Consideration should be given to insulating the piping surfaces to avoid condensation. ClimateMaster recommends unit insulation any time the water temperature is expected to be below 15.6°C. Metal to plastic threaded joints should never be used due to their tendency to leak over time.

Teflon® tape thread sealant is recommended to minimize internal fouling of the heat exchanger. Do not over tighten connections and route piping so as not to interfere with service or maintenance access. Hose kits are available from ClimateMaster in different configurations as shown in Figure 12 for connection between the unit and the piping system. Depending upon selection, hose kits may include shut off valves, P/T plugs for performance measurement, high pressure stainless steel braided hose, "Y" type strainer with blow down valve, and/or "J" type swivel connection. Balancing valves and an external low pressure drop solenoid valve for use in variable speed pumping systems may also be included in the hose kit. The piping system should be flushed to remove dirt, piping chips, and other foreign material prior to operation (see "Piping System Cleaning and Flushing Procedures" in this manual). The flow rate is usually set between 2.9 and 4.5 I/m per kW of cooling capacity. ClimateMaster recommends 3.9 I/m per kW for most applications of water loop heat pumps. To ensure proper maintenance and servicing, P/T ports are imperative for temperature and flow verification, as well as performance checks.

Water loop heat pump (cooling tower/boiler) systems typically utilize a common loop, maintained between 16 - 32°C. The use of a closed circuit evaporative cooling tower with a secondary heat exchanger between the tower and the water loop is recommended. If an open type cooling tower is used continuously, chemical treatment and filtering will be necessary.



Figure 12: Typical Water-Loop Application

Low Water Temperature Cutout Setting

CXM2 - When antifreeze is selected, the FP1 jumper (JW3) should be clipped to select the low temperature (antifreeze -12.2°C) setpoint and avoid nuisance faults (see "Low Water Temperature Cutout Selection" in this manual). **Note: Low water temperature operation requires extended range equipment.**

Ground-Loop Heat Pump Applications

CAUTION! 🧍

CAUTION! The following instructions represent industry accepted installation practices for closed loop earth coupled heat pump systems. Instructions are provided to assist the contractor in installing trouble free ground loops. These instructions are recommendations only. State/provincial and local codes MUST be followed and installation MUST conform to ALL applicable codes. It is the responsibility of the installing contractor to determine and comply with ALL applicable codes and regulations.

CAUTION! 🧴

CAUTION! Ground loop applications require extended range equipment and optional refrigerant/water circuit insulation.

Pre-Installation

Prior to installation, locate and mark all existing underground utilities, piping, etc. Install loops for new construction before sidewalks, patios, driveways, and other construction has begun. During construction, accurately mark all ground loop piping on the plot plan as an aid in avoiding potential future damage to the installation.

Piping Installation

The typical closed loop ground source system is shown in Figure 13. All earth loop piping materials should be limited to polyethylene fusion only for in-ground sections of the loop. Galvanized or steel fittings should not be used at any time due to their tendency to corrode. All plastic to metal threaded fittings should be avoided due to their potential to leak in earth coupled applications. A flanged fitting should be substituted. P/T plugs should be used so that flow can be measured using the pressure drop of the unit heat exchanger.

Earth loop temperatures can range between -4 to 43°C. Flow rates between 2.41 to 3.23 l/m per kW of cooling capacity is recommended in these applications. Test individual horizontal loop circuits before backfilling. Test vertical U-bends and pond loop assemblies prior to installation. Pressures of at least 689 kPa should be used when testing. Do not exceed the pipe pressure rating. Test entire system when all loops are assembled.

Flushing the Earth Loop

Upon completion of system installation and testing, flush the system to remove all foreign objects and purge to remove all air.

Antifreeze

In areas where minimum entering loop temperatures drop below 5°C or where piping will be routed through areas subject to freezing, antifreeze is required. Alcohols and glycols are commonly used as antifreeze; however your local sales office should be consulted to determine the antifreeze best suited to your area. Freeze protection should be maintained to 9°C below the lowest expected entering loop temperature. For example, if -1°C is the minimum expected entering loop temperature, the leaving loop temperature would be -4 to -6°C and freeze protection should be at -10°C. Calculation is as follows: -1°C - 9°C = -10°C.

All alcohols should be premixed and pumped from a reservoir outside of the building when possible or introduced under the water level to prevent fumes. Calculate the total volume of fluid in the piping system. Then use the percentage by volume shown in table 2 for the amount of antifreeze needed. Antifreeze concentration should be checked from a well mixed sample using a hydrometer to measure specific gravity.

Table 2: Antifreeze Percentages by Volume

Tune	Minimum Temperature for Low Temperature Protection								
туре	-12.2°C	-9.4°C	-6.7°C	-3.9°C					
Methanol 100% USP food grade Propylene Glycol Ethanol*	25% 38% 29%	21% 25% 25%	16% 22% 20%	10% 15% 14%					

* Must not be denatured with any petroleum based product

Ground-Loop Heat Pump Applications, Cont'd.



Figure 13: Typical Ground-Loop Application

Ground-Water Heat Pump Applications

Open Loop - Ground Water Systems

Typical open loop piping is shown in Figure 14. Shut off valves should be included for ease of servicing. Boiler drains or other valves should be "tee'd" into the lines to allow acid flushing of the heat exchanger. Shut off valves should be positioned to allow flow through the coax via the boiler drains without allowing flow into the piping system. P/T plugs should be used so that pressure drop and temperature can be measured.

🚹 WARNING! 🧍

WARNING! Polyolester Oil, commonly known as POE oil, is a synthetic oil used in many refrigeration systems including those with HFC-410A refrigerant. POE oil, if it ever comes in contact with PVC or CPVC piping, may cause failure of the PVC/CPVC. PVC/CPVC piping should never be used as supply or return water piping with water source heat pump products containing HFC-410A as system failures and property damage may result.

Water quantity should be plentiful and of good quality. Consult table 3 for water quality guidelines. The unit can be ordered with either a copper or cupro-nickel water heat exchanger. Consult Table 3 for recommendations. Copper is recommended for closed loop systems and open loop ground water systems that are not high in mineral content or corrosiveness. In conditions anticipating heavy scale formation or in brackish water, a cupro-nickel heat exchanger is recommended. In ground water situations where scaling could be heavy or where biological growth such as iron bacteria will be present, an open loop system is not recommended. Heat exchanger coils may over time lose heat exchange capabilities due to build up of mineral deposits. Heat exchangers must only be serviced by a qualified technician, as acid and special pumping equipment is required. Desuperheater coils can likewise become scaled and possibly plugged. In areas with extremely hard water, the owner should be informed that the heat exchanger may require occasional acid flushing. In some cases, the desuperheater option should not be recommended due to hard water conditions and additional maintenance required.

Water Quality Standards

Table 3 should be consulted for water quality requirements. Scaling potential should be assessed using the pH/Calcium hardness method. If the pH <7.5 and the calcium hardness is less than 100 ppm, scaling potential is low. If this method yields numbers out of range of those listed, the Ryznar Stability and Langelier Saturation indecies should be calculated. Use the appropriate scaling surface temperature for the application, 66°C for direct use (well water/open loop) and DHW (desuperheater); 32°C for indirect use. A monitoring plan should be implemented in these probable scaling situations. Other water quality issues such as iron fouling, corrosion prevention and erosion and clogging should be referenced in Table 3.

Expansion Tank and Pump

Use a closed, bladder-type expansion tank to minimize mineral formation due to air exposure. The expansion tank should be sized to provide at least one minute continuous run time of the pump using its drawdown capacity rating to prevent pump short cycling. Discharge water from the unit is not contaminated in any manner and can be disposed of in various ways, depending on local building codes (e.g. recharge well, storm sewer, drain field, adjacent stream or pond, etc.). Most local codes forbid the use of sanitary sewer for disposal. Consult your local building and zoning department to assure compliance in your area.

Water Control Valve

Note the placement of the water control valve in Figure 14. Always maintain water pressure in the heat exchanger by placing the water control valve(s) on the discharge line to prevent mineral precipitation during the off-cycle. Pilot operated slow closing valves are recommended to reduce water hammer. If water hammer persists, a mini-expansion tank can be mounted on the piping to help absorb the excess hammer shock. Ensure that the total 'VA' draw of the valve can be supplied by the unit transformer. For instance, a slow closing valve can draw up to 35VA. This can overload smaller 40 or 50 VA transformers depending on the other controls in the circuit. A typical pilot operated solenoid valve draws approximately 15VA (see Figure 21). NOTE: the special wiring diagrams for slow closing valves (Figures 22 & 23).

Flow Regulation

Flow regulation can be accomplished by two methods. One method of flow regulation involves simply adjusting the ball valve or water control valve on the discharge line. Measure the pressure drop through the unit heat exchanger, and determine flow rate from Tables 8a through 8e. Since the pressure is constantly varying, two pressure gauges may be needed. Adjust the valve until the desired flow of 2.0 to 2.6 l/m per kW is achieved. A second method of flow control requires a flow control device mounted on the outlet of the water control valve. The device is typically a brass fitting with an orifice of rubber or plastic material that is designed to allow a specified flow rate. On occasion, flow control devices may produce velocity noise that can be reduced by applying some back pressure from the ball valve located on the discharge line. Slightly closing the valve will spread the pressure drop over both devices, lessening the velocity noise. NOTE: When EWT is below 10°C, 2.6 l/m per kW is required.

Ground-Water Heat Pump Applications, Cont'd.

Water Coil Low Temperature Limit Setting

For all open loop systems the -1.1°C FP1 setting (factory setting-water) should be used to avoid freeze damage to the unit. See "Low Water Temperature Cutout Selection" in this manual for details on the low limit setting.





Water Quality Standards

Table 3: Water Quality Standards

Water Quality Parameter	HX Material	Closed Recirculating	Open Loop and Recirculating Well							
Scaling Potential - Primary I	Measuren	nent								
Above the given limits, scaling is likely to	occur. Scallr	ig indexes should be calc	ulated using the limits be	IOW						
Method	All	-	pH < 7	7.5 and Ca Hardness <	100ppm					
Index Limits for Probable Scaling Situations - (Operation outside these limits is not recommended)										
Scaling indexes should be calculated at A monitoring plan should be implemented	66°C for dire	ct use and HWG applicati	ions, and at 32°C for indi	rect HX use.						
Ryznar Stability Index	All	-	lf >	6.0 - 7.5 7.5 minimize steel pipe	use.					
Langelier Saturation Index	All	-	lf <-0.5 minimize stee	-0.5 to +0.5 I pipe use. Based upon Direct well, 29°C Indirec	66°C HWG and t Well HX					
Iron Fouling		•	•	· · · · ·						
Iron Fe ²⁺ (Ferrous) (Bacterial Iron potential)	All	-	If Fe²⁺ (ferrous)>0.2 ppm	<0.2 ppm (Ferrous) with pH 6 - 8, O2<5 ppr	n check for iron bacteria.					
Iron Fouling	All	-	<0.5 ppm of Oxygen Above this level deposition will occur.							
Corrosion Prevention	•	•	•							
		6 - 8.5		6 - 8.5						
pH	All	Monitor/treat as needed	Minimize steel pipe below 7 and no open tanks with pH <8							
Hydrogen Sulfide (H ₂ S)	All	-	At H ₂ S>0.2 ppm, avoid Rotten e Copper alloy (bronze	<0.5 ppm I use of copper and copp gg smell appears at 0.5 or brass) cast component	per nickel piping or HX's. ppm level. nts are OK to <0.5 ppm.					
Ammonia ion as hydroxide, chloride, nitrate and sulfate compounds	All	-		<0.5 ppm						
			Maximum Allo	owable at maximum wat	er temperature.					
			10°C	24°C	38 °C					
Maximum	Copper	-	<20ppm	NR	NR					
Chloride Levels	Cupronickel	-	<150 ppm	NR	NR					
	304 55	-	<400 ppm	<250 ppm	<150 ppm					
	Titanium	-	<1000 ppm >1000 ppm	<550 ppm	< 375 ppm					
Erosion and Clogging										
Particulate Size and Erosion	All	<10 ppm of particles and a maximum velocity of 1.8 m/s Filtered for maximum 841 micron [0.84 mm, 20 mesh] size.	<10 ppm (<1 ppm "sandfree" for reinjection) of particles and a maximu velocity of 1.8 m/s. Filtered for maximum 841 micron 0.84 mm, 20 mesh] size. Any particulate that is not removed can potentially clog components.							

The ClimateMaster Water Quality Table provides water quality requirements for ClimateMaster coaxial heat exchangers and fluid coolers. The water should be evaluated by an independent testing facility comparing to this Table and when properties are outside of these requirements, an external secondary heat exchanger must be used to isolate the equipment from the unsuitable water. Failure to do so will void the warranty for the coaxial heat exchanger and any other components damaged by a leak.

Notes:

Closed Recirculating system is identified by a closed pressurized piping system.
 Recirculating open wells should observe the open recirculating design considerations.
 NR - Application not recommended.

• "-" No design Maximum.

Electrical – Line Voltage

Electrical – Line Voltage - All field installed wiring, including electrical ground, must comply with the National Electrical Code as well as all applicable local codes. Refer to the unit electrical data for fuse sizes. Consult wiring diagram for field connections that must be made by the installing (or electrical) contractor. All final electrical connections must be made with a length of flexible conduit to minimize vibration and sound transmission to the building.

General Line Voltage Wiring - Be sure the available power is the same voltage and phase shown on the unit serial plate. Line and low voltage wiring must be done in accordance with local codes or the National Electric Code, whichever is applicable.

VARNING! 🧍

WARNING! To avoid possible injury or death due to electrical shock, open the power supply disconnect switch and secure it in an open position during installation.

Transformer

On dual voltage units the installer must confirm that the power supply and unit transformer wiring match. Installer must rewire as needed. Refer to the unit wiring diagram for proper connections.

CAUTION! 🥂

CAUTION! Use only copper conductors for field installed electrical wiring. Unit terminals are not designed to accept other types of conductors.

ዾ WARNING! 🥂

WARNING! This appliance must be installed by a qualified electrician who is fully aware of current safety and installations regulations. Pursuant to IEC 60335-1 Section 22.2, the installer is required to connect this appliance to the electricity supply by means of an all-pole disconnect.

Electrical Data

TCH/V Standard Unit

тс	Voltage	Rated	Voltage	Co	ompress	sor	Fan	Total	Min	Max	
Model	Code	Voltage	Min/Max	QTY	RLA	LRA	FLA	FLA	Amp	Fuse	
006	V	220/240/50/1	209/252	1	2.8	15.0	0.4	3.2	3.9	15	
009	V	220/240/50/1	209/252	1	3.1	18.8	0.7	3.8	4.6	15	
012	V	220/240/50/1	209/252	1	4.0	21.0	0.7	4.7	5.7	15	
015	V	220/240/50/1	209/252	1	4.7	23.0	0.9	5.6	6.7	15	
018	V	220/240/50/1	209/252	1	5.9	24.0	0.9	6.8	8.2	15	
024	V	220/240/50/1	209/252	1	9.0	52.0	1.3	10.3	12.6	20	
020	V	220/240/50/1	209/252	1	11.2	60.0	2.7	13.9	16.7	25	
030	U	380/420/50/3	361/436	1	3.9	28.0	1.7	5.6	6.6	15	
026	V	220/240/50/1	209/252	1	13.5	67.0	2.0	15.5	18.9	30	
030	U	380/420/50/3	361/436	1	5.4	38.0	1.2	6.6	8.0	15	
042	U	380/420/50/3	361/436	1	6.0	46.0	1.7	7.7	9.2	15	
048	U	380/420/50/3	361/436	1	6.1	43.0	1.8	7.9	9.4	15	
060	U	380/420/50/3	361/436	1	7.8	51.5	2.5	10.3	12.3	20	

All fuses Class RK-5

TCH/V High Static Unit

тс	Voltage	Rated	Voltage	Co	mpress	sor	Fan	Total	Min	Max
Model	Code	Voltage	Min/Max	QTY	RLA	LRA	FLA	FLA	Amp	Fuse
015	V	220/240/50/1	209/252	1	4.7	23.0	0.9	5.6	6.7	15
018	V	220/240/50/1	209/252	1	5.9	24.0	1.3	7.2	8.7	15
024	V	220/240/50/1	209/252	1	9	52.0	2.7	11.7	14.0	20
	V	220/240/50/1	209/252	1	11.2	60.0	2.7	13.9	16.7	25
030	U	380/420/50/3	361/436	1	3.9	28.0	1.7	5.6	6.6	15
026	V	220/240/50/1	209/252	1	13.5	67.0	2.7	16.2	19.6	30
036	U	380/420/50/3	361/436	1	5.4	38.0	1.7	7.1	8.5	15
042	U	380/420/50/3	361/436	1	6	46.0	1.7	7.7	9.2	15
048	U	380/420/50/3	361/436	1	6.1	43.0	2.5	8.6	10.1	15
060	U	380/420/50/3	361/436	1	7.8	51.5	2.6	10.4	12.4	20

All fuses Class RK-5

TCH/V ECM Motor Unit

тс	Voltage	Data di Valiana	"Voltage		Compres	sor	Fan	Total	Min	Max
Model	Code	Rated voltage	Min/Max"	Qty	RLA	LRA	FLA	FLA	Amp	Fuse
006	V	220-240/50/1	206.8 / 254.4	1	2.14	15.0	2.30	4.4	5.0	15
009	V	220-240/50/1	206.8 / 254.4	1	3.10	18.8	2.30	5.4	6.2	15
012	V	220-240/50/1	206.8 / 254.4	1	4.05	21.0	2.30	6.4	7.4	15
015	V	220-240/50/1	206.8 / 254.4	1	4.70	23.0	2.60	7.3	8.5	15
018	V	220-240/50/1	206.8 / 254.4	1	5.90	24.0	2.60	8.5	10.0	15
024	V	220-240/50/1	206.8 / 254.4	1	9.00	52.0	4.60	13.6	15.9	20
030	V	220-240/50/1	206.8 / 254.4	1	11.20	60.0	4.60	15.8	18.6	25
030	U	380-420/50/3	357.2 / 445.2	1	3.90	28.0	1.10	5.0	6.0	15
036	V	220-240/50/1	206.8 / 254.4	1	13.50	67.0	4.60	18.1	21.5	30
030	U	380-420/50/3	357.2 / 445.2	1	5.40	38.0	1.10	6.5	7.9	15
042	U	380-420/50/3	357.2 / 445.2	1	6.00	46.0	1.10	7.1	8.6	15
048	U	380-420/50/3	357.2 / 445.2	1	6.10	43.0	2.10	8.2	9.7	15
060	U	380-420/50/3	357.2 / 445.2	1	7.80	51.5	2.10	9.9	11.9	15

All fuses Class RK-5

THE SMART SOLUTION FOR ENERGY EFFICIENCY

Tranquility 16 (TC) Series Rev.: 24 January, 2023

Eletrical – Power Wiring

🚹 WARNING! 🖊

WARNING! Disconnect electrical power source to prevent injury or death from electrical shock.

🚹 CAUTION! 🧍

CAUTION! Use only copper conductors for field installed electrical wiring. Unit terminals are not designed to accept other types of conductors.

Electrical – Line Voltage - All field installed wiring, including electrical ground, must comply with the National Electrical Code as well as all applicable local codes. Refer to the unit electrical data for fuse sizes. Consult wiring diagram for field connections that must be made by the installing (or electrical) contractor. All final electrical connections must be made with a length of flexible conduit to minimize vibration and sound transmission to the building.

General Line Voltage Wiring - Be sure the available power is the same voltage and phase shown on the unit serial plate. Line and low voltage wiring must be done in accordance with local codes or the National Electric Code, whichever is applicable.

Figure 16: TC Single Phase Line Voltage Field Wiring. Three phase wiring is similar except that all three power wires are directly connected to the contactor.



Power Connection

Line voltage connection is made by connecting the incoming line voltage wires to the "L" side of the contactor as shown in Figures 16. Consult electrical tables for correct fuse size.

Transformer

On dual voltage units the installer must confirm that the power supply and unit transformer wiring match. Installer must rewire as needed. Refer to the unit wiring diagram for proper connections.

Blower Speed Selection – Units with PSC Motor

PSC (Permanent Split Capacitor) blower fan speed can be changed by moving the blue wire on the fan motor terminal block to the desired speed as shown in Figure 17. Most ClimateMaster units are shipped on the medium speed tap. Consult submittal data or engineering design guide for specific unit airflow tables. Typical unit design delivers rated airflow at nominal static 37Pa on medium speed and rated airflow at a higher static 100 to 125 Pa on high speed for applications where higher static is required. Low speed will deliver approximately 85% of rated airflow at 25 Pa. An optional high static blower is available on some models.

Electrical – Power & Low Voltage Wiring

Special Note for AHRI Testing: To achieve rated airflow for AHRI testing purposes on all PSC products, it is necessary to change the fan speed to "HI" speed. When the heat pump has experienced less than 100 operational hours and the coil has not had sufficient time to be "seasoned", it is necessary to clean the coil with a mild surfactant such as Calgon to remove the oils left by manufacturing processes and enable the condensate to properly "sheet" off of the coil.

Figure 17: PSC Motor Speed Selection



ELECTRICAL - LOW VOLTAGE WIRING

Thermostat Connections

The thermostat should be wired directly to the CXM2 or DXM2.5 board. Figure 19 shows low voltage wiring. See "Electrical – Thermostat" for specific terminal connections. Review the appropriate AOM (Application, Operation and Maintenance) manual for units with DDC controls.

Low Water Temperature Cutout Selection

The CXM2/DXM2.5 control allows the field selection of low water (or water-antifreeze solution) temperature limit by clipping jumper JW3, which changes the sensing temperature associated with thermistor FP1. Note that the FP1 thermistor is located on the refrigerant line between the coaxial heat exchanger and expansion device (TXV or cap tube). Therefore, FP1 is sensing refrigerant temperature, not water temperature, which is a better indication of how water flow rate/ temperature is affecting the refrigeration circuit.

The factory setting for FP1 is for systems using water -1.1°C refrigerant temperature). In low water temperature (extended range) applications with antifreeze (most ground loops), jumper JW3 should be clipped as shown in Figure 20 to change the setting to -12.2°C refrigerant temperature, a more suitable temperature when using an antifreeze solution. All ClimateMaster units operating with entering water temperatures below 15°C must include the optional water/refrigerant circuit insulation package to prevent internal condensation.

Figure 19: Low Voltage Field Wiring



Valve

Figure 20: FP1 Limit Setting ۲ CC 0 CCG O KI RELAY COM ۲ 0 0 0 oro **O** TEST ID. 0 DED ഹ BLU Ģ лı J3 G FAULT (G) Statu (q) .T2 LT2 BLED/ENABLED RVS ESD 1 OPG 1 0 со 24V DC SEE I.O.M. FOR DIP SWITCH DEFINITIONS EHI 74 T3 EH2

Accessory Connections

A terminal paralleling the compressor contactor coil has been provided on the CXM2/DXM2.5 control. Terminal "A" is designed to control accessory devices, such as water valves. Note: This terminal should be used only with 24 Volt signals and not line voltage. Terminal "A" is energized with the compressor contactor. See Figure 19 or the specific unit wiring diagram for details.

Low Voltage VA Ratings

Component	VA
Typical Blower Relay	6 - 7
Typical Reversing Valve Solenoid	4 - 6
30A Compressor Contactor	6 - 9
Subtotal	16 - 22
+ CXM2 board (5 - 9 VA)*	21 - 31
Remaing VA for Accessories	19 - 29
+ DXM2.5 board (8 - 12 VA)*	24 - 34
Remaing VA for Accessories	41 - 51

*Standard transformer for CXM2 board is 50VA. Optional DXM2.5 board and/or DDC controls include 75VA transformer.

Figure 21: Accessory Wiring **Terminal Strip** С Typical 24VAC Water

Α

Electrical – Low Voltage Wiring

Water Solenoid Valves - An external solenoid valve(s) should be used on ground water installations to shut off flow to the unit when the compressor is not operating. A slow closing valve may be required to help reduce water hammer. Figure 19 shows typical wiring for a 24VAC external solenoid valve. Figures 20 and 21 illustrate typical slow closing water control valve wiring for Taco 500 series (ClimateMaster P/N AVM) and Taco SBV series valves. Slow closing valves take approximately 60 seconds to open (very little water will flow before 45 seconds). Once fully open, an end switch allows the compressor to be energized. Only relay or triac based electronic thermostats should be used with slow closing valves. When wired as shown, the slow closing valve will operate properly with the following notations:

- The valve will remain open during a unit lockout. 1
- 2. The valve will draw approximately 25-35 VA through the "Y" signal of the thermostat.

Note: This valve can overheat the anticipator of an electromechanical thermostat. Therefore, only relay or triac based thermostats should be used.

climatemaster com

Blower Performance Data – Standard Unit

	Fan	Rated	Min			Airf	low (l/s) at Ext	ernal St	atic Pre	essure (Pa.)		
Model	Speed	Airflow (I/s)	(l/s)	0	25	50	75	100	125	150	175	200	225	250
	н				112	105	98	83	65					
TCH/V 006	MED	79	54		94	87	76	68						
	LOW				76	68	58		-					
	н				145	134	124	113	99					
TCH/V 009	MED	121	85		138	127	113	102	92					
	LOW				120	114	106	92						
	н				170	162	155	144	137	116				
TCH/V 012	MED	144	108		151	144	137	130	123					
	LOW				130	126	116	112						
	н				269	255	248	230	195	163				
TCH/V 015	MED	192	140	248	241	234	223	212	184					
	LOW			219	212	205	198	184	163					
	Н	Н			269	255	248	230	195					
TCH/V 018	MED	230	167	248	241	234	223	212	184					
	LOW			219	212	205	198	184						
	н	_						343	319	298	264			
TCH/V 024	MED	274	241	346	340	329	316	302	285	264				
	LOW			281	274	268	261	250						
	н						398	377	353	326	288			
TCH/V 030	MED	343	285	429	412	394	374	357	333	305				
	LOW			384	367	353	336	319	298					
	н			532	518	501	480	462	424	389				
TCH/V 036	MED	412	350	424	399	396	392	385	364					
	LOW			354	350			1						
	н	_		563	542	521	497	470	443	408				
042	MED	480	406	511	494	477	460	436	408	384				
	LOW			_			1			1				
	ні	_			1	679	655	617	576	511				
048	MED	549	484	665	652	638	607	587	549	484				
	LOW			607	593	580	566	539	497					
TOUR	н	-		793	789	778	750	729	711	694	665	633		
060	MED	686	603	725	722	704	686	669	648	630	605			
	LOW			655	651	640	630	612						

Black areas denote ESP where operation is not recommended.

Units factory shipped on medium speed. Other speeds require field selection.

All airflow is rated and shown above at the lower voltage if unit is dual voltage rated, e.g. 220V for 220-240V units.

Performance stated is at the rated power supply, performance may vary as the power supply varies from the rated.

Blower Performance Data – High Static Unit

Martal	Fan	Rated	Min			Airf	low (I/s)	at Exte	ernal St	atic Pre	essure (Pa.)		
Model	Speed	Airtiow (l/s)	Airtiow (l/s)	0	25	50	75	100	125	150	175	200	225	250
	HI					276	269	258	244	230	188			
TCH/V 015	MED	192	140	265	255	248	237	234	223	212	173			
	LOW			237	226	219	212	205	202	188				
	HI					276	269	258	244	230	188			
TCH/V 018	MED	230	167	265	255	248	237	234	223	212	173			
	LOW			237	226	219	212	205	202	188				
	HI								353	326	288			
1 TCH/V 024	MED	274	241					357	333	305	257			
•= ·	LOW					353	336	319	298	271	244			
	HI								398	357	316			
TCH/V 030	MED	343	285					388	353	319				
	LOW			360	353	340	329	312	288					
	HI							536	515	490	452	410		
1CH/V 036	MED	412	350	476	469	462	455	441	431	403	375			
	LOW			361	354	350								
701107	HI			0	0	532	521	504	497	473	425			
042	MED	480	406	477	470	463	453	446	429	405	370			
	LOW													
	HI							707	689	672	645	614	569	518
1CH/V 048	MED	549	484	703	700	683	665	648	628	611	587	556	511	
	LOW			635	631	621	611	593	573	549	518			
	HI			849	846	839	828	814	793	778	754	729	701	669
TCH/V 060	MED	686	603	764	761	757	736	722	715	701	683	665	527	619
	LOW			683	679	676	669	665	655	648	637	619		

Black areas denote ESP where operation is not recommended.

Units factory shipped on medium speed. Other speeds require field selection.

All airflow is rated and shown above at the lower voltage if unit is dual voltage rated, e.g. 220V for 220-240V units.

Performance stated is at the rated power supply, performance may vary as the power supply varies from the rated.

ECM Motor – Blower Performance Data – Standard Unit

<table-container>Meet Meet</table-container>	Airflow in I/s	with wet co	oil and clea	n air filter												
Model (VIS) Airflow (VIS) Airflow (VIS) Airflow (VIS) Airflow (VIS) Airflow (VIS) Airflow (VIS) Airflow (VIS) Airflow (VIS) 128 110 111 101 94 88 82 A A Speed (PCH) 59eed (PCH) 1236 1312 1401 1499 1600 1695 1785 3 3 3 117 108 99 92 85 79 74 3 Speed (PCH) 1110 99 92 85 79 74 3 Speed (PCH) 1205 1287 1389 1400 1588 1684 1770 4 Airflow (Vis) Speed (PCH) 1156 1207 1321 1428 1534 1623 1709 1802 11 99 90 32 36 38 941 44 48 160 1165 1207 1321 1428 1534 1623 1709 1802		Fan	Rated	Min					Exte	rnal Sta	tic Pres	sure (Pa	a.)			
A Airlow (l/s) 128 119 111 101 94 88 82 3 Speed (RPM) 1236 1312 1401 1499 1600 1605 1785 3 3 40 42 45 49 52 56 3 3 40 42 45 49 52 56 3 3 35 138 140 44 47 51 4 67 61 58 59ed (RPM) 1115 1207 1321 1428 1534 1623 1709 1802 111 99 90 82 71 824 67 61 58 1116 920 1112 1337 1428 1534 1644 44 44 44 44 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 48 4	Model	Speed	Airflow (I/s)	Airflow (I/s)		0	25	50	75	100	125	150	175	200	225	250
4 5 Speed (RPM) 1236 1312 1401 1499 1600 1695 1785 3 3 3 40 42 45 49 52 56 3 3 40 42 45 49 52 56 2 3 117 108 99 92 85 79 74 3 33 36 38 41 44 47 51 2 4 67 61 58 684 1709 1802 9 90 82 74 67 61 58 9 600 33 36 39 41 44 48 1600 1009 92 1112 1237 1351 1428 1534 1434 14 44 48 77 165 157 74 14 44 48 1600 158 178 178					Airflow (I/s)		128	119	111	101	94	88	82			
Image: constraint of the section of the sectin of the section of the section of the section of the sect		4			Speed (RPM)	-	1236	1312	1401	1499	1600	1695	1785			
Airdow (vis) 117 108 99 92 85 79 74 3 3 53 Speed (RPM) 1205 1287 1389 1490 1558 1684 1770 2 2 1 Speed (RPM) 1115 1205 1287 1389 1490 1558 1684 1770 1 Speed (RPM) 1115 1207 1321 1428 1534 1623 1709 1802 1 Speed (RPM) 91 80 70 60 53 53 59eed (RPM) 199 90 91 180 53 1654 1623 1709 1802 1 Power (W) 20 22 24 27 29 30 33 36 39 41 44 48 48 170 165 164 1680 1768 176 1820 774 79 174 175 155 164 176 1658 1774					Power (W)	-	37	40	42	45	49	52	56	-		
3 79 53 Speed (RPM) 1205 1287 1389 1490 1588 1684 1770 2 0 0 0 79 53 0 0 0 0 74 67 61 58 2 0 0 0 74 67 61 58 9 0 0 128 133 35 38 41 44 47 61 58 0			-		Airflow (I/s)		117	108	99	92	85	79	74	-		
TCH/V 006 79 53 Power (W) 33 35 38 41 44 47 51 2 2 2 3 35 38 41 44 47 51 4 4 40 47 51 58 58 58 41 44 44 47 51 4 2 2 30 33 36 39 41 44 48 1 99 90 82 74 67 61 58 9 90 30 33 36 39 41 44 48 10 1156 1207 1321 1458 1534 1623 176 153 11 99 90 82 72 29 34 145 145 156 165 167 163 156 149 142 3 121 87 Speed (RPM) 165 168		3			Speed (RPM)	-	1205	1287	1389	1490	1588	1684	1770	-		
1 1			70		Power (W)		33	35	38	41	44	47	51	-		
2 3 101 102 103 104 104 44 44 44 44 44 44 44 44 44 46 102 102 102 102 102 102 102 102 103 104 44 44 44 44 46 102 102 102 102 102 102 103 </td <td>TCH/V 006</td> <td></td> <td>. 79</td> <td>53</td> <td>Airflow (I/s)</td> <td>-</td> <td>111</td> <td>99</td> <td>90</td> <td>82</td> <td>74</td> <td>67</td> <td>61</td> <td>58</td> <td></td> <td></td>	TCH/V 006		. 79	53	Airflow (I/s)	-	111	99	90	82	74	67	61	58		
1 100		2			Speed (RPM)	-	1156	1207	1321	1428	1534	1623	1709	1802		
Airflow (i/s) 91 80 70 60 53 Speed (RPM) 992 1112 1237 1351 1454 Power (W) 20 22 24 27 29 4 Power (W) 185 178 171 165 157 3 Airflow (i/s) 185 178 171 165 157 Airflow (i/s) 1851 1644 1706 1767 1820 176 Power (W) 79 83 86 90 91 4					Power (W)	-	29	30	33	36	39	41	44	48		
1 Speed (RPM) 992 1112 1237 1351 1454 Power (W) 20 22 24 27 29 4 Power (W) 185 178 171 165 157 3 Airflow (Us) 185 178 170 163 156 149 142 3 Airflow (Us) 170 163 156 149 142 3 Airflow (Us) 170 163 156 149 142 3 Airflow (Us) 170 163 156 149 142 2 Airflow (Us) 170 163 156 149 142 4 Power (W) 513 145 131 122 115 3 1450 156 139 131 122 115 11 Power (W) 1369 1438 1516 1603 1695 1774 11 Power (W) 34 36 40 </td <td></td> <td></td> <td>-</td> <td></td> <td>Airflow (I/s)</td> <td>-</td> <td>91</td> <td>80</td> <td>70</td> <td>60</td> <td>53</td> <td></td> <td>I</td> <td></td> <td></td> <td></td>			-		Airflow (I/s)	-	91	80	70	60	53		I			
Image: constraint of the second sec		1			Speed (RPM)	-	992	1112	1237	1351	1454					
4 Airflow (i/s) 185 178 171 165 157 3 3 3 86 90 91					Power (W)	-	20	22	24	27	29					
4 Speed (RPM) 1581 1644 1706 1767 1820 3 3 3 86 90 91 170 163 156 149 142 3 3 121 87 170 163 156 149 142 2 Speed (RPM) 170 163 156 149 142 3 Power (W) 65 68 71 74 79 4 Power (W) 153 145 139 131 122 115 3 Mirflow (I/s) 153 145 139 131 122 115 3 Nower (W) 51 54 57 61 64 68 Airflow (I/s) 127 118 107 97 89 36 Power (W) 34 36 40 42 44 44 476 1563 Power (W) 34 36 102 1764<		4			Airflow (I/s)	-	185	178	171	165	157					
Image: constraint of the section of the sectin of the section of the section of the section of the sect					Speed (RPM)	-	1581	1644	1706	1767	1820					
Airflow (l/s) 170 163 156 149 142 3 3 3 3 3 3 3 3 3 3 3 3 3 3 121 Speed (RPM) 1487 1550 1614 1678 1768 1768 2 2 3 141 122 115 116 116 116 116 116 116 116 116 116 116 116 116 116 116 116 116 116 116					Power (W)		79	83	86	90	91					
$ \begin{tabular}{ c c c c c c c c c c c c c c c c c c c$					Airflow (I/s)	-	170	163	156	149	142					
$ \begin{array}{ c c c c c c c } \hline \begin{tabular}{ c c c c } \hline \begin{tabular}{ c c c c c } \hline \begin{tabular}{ c c c c c c } \hline \begin{tabular}{ c c c c c c c c } \hline \begin{tabular}{ c c c c c c c c } \hline \begin{tabular}{ c c c c c c c } \hline \begin{tabular}{ c c c c c c c c c c c c c c c c c c c$		3			Speed (RPM)		1487	1550	1614	1678	1768					
1 1			121	87	Power (W)		65	68	71	74	79					
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	101// 003		121	07	Airflow (I/s)		153	145	139	131	122	115				
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		2			Speed (RPM)	_	1369	1438	1516	1603	1695	1774				
$ \begin{tabular}{ c c c c c c c c c c c c c c c c c c c$					Power (W)		51	54	57	61	64	68				
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$					Airflow (I/s)	_	127	118	107	97	89					
Image: Constraint of the state of		1			Speed (RPM)	_	1195	1276	1385	1476	1563					
Airflow (I/s) 202 196 190 184 179 174 K Speed (RPM) 1588 1627 1672 1718 1764 1811 Power (W) 109 112 115 118 121 124 Airflow (I/s) 182 175 169 162 156 150 144 Speed (RPM) 1469 1514 1561 1608 1659 1711 1778 Power (W) 84 87 89 92 95 98 102 Airflow (I/s) 165 158 151 145 138 131 125 118 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (I/s) 142 134 126 118 110 151 151 1					Power (W)		34	36	40	42	44					
4 Speed (RPM) 1588 1627 1718 1764 1811 Power (W) 109 112 115 118 121 124 3 Airflow (l/s) 182 175 169 162 156 150 144 2 114 109 112 115 118 121 124 Airflow (l/s) 182 175 169 162 156 150 144 Power (W) 84 87 89 92 95 98 102 Airflow (l/s) 165 158 151 145 138 131 125 118 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (l/s) 142 134 126 118 110 1767 1819					Airflow (I/s)	-	202	196	190	184	179	174				
TCH/V 012 144 Power (W) 109 112 115 118 121 124 3 Airflow (l/s) 182 175 169 162 156 150 144 2 104 Speed (RPM) 1469 1514 1561 1608 1659 1711 1778 Power (W) 84 87 89 92 95 98 102 Airflow (l/s) 165 158 151 145 138 131 125 118 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (l/s) 142 134 126 118 110 1567 158 151 145 158 151 145 158 151 145 158 151 145 156 158		4			Speed (RPM)	-	1588	1627	1672	1718	1764	1811				
3 3 Airflow (l/s) 182 175 169 162 156 150 144 2 144 Speed (RPM) 1469 1514 1561 1608 1659 1711 1778 Power (W) 84 87 89 92 95 98 102 Airflow (l/s) 165 158 151 145 138 131 125 118 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (l/s) 142 134 126 118 110 1767 1819					Power (W)	-	109	112	115	118	121	124				
TCH/V 012 2 144 104 Speed (R-M) 1469 1514 1501 1608 1659 1711 1778 2 104 104 Power (W) 84 87 89 92 95 98 102 2 Airflow (l/s) 165 158 151 145 138 131 125 118 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (l/s) 142 134 126 118 110 1107 1767 1819					Airflow (I/s)	-	182	1/5	169	162	156	150	144	-		
2 144 104 Power (W) 84 87 89 92 95 96 102 2 144 104 Airflow (I/s) 165 158 151 145 138 131 125 118 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (I/s) 142 134 126 118 110 <td></td> <td rowspan="3">3 TCH/V 012</td> <td></td> <td></td> <td>Speed (RPM)</td> <td>-</td> <td>1469</td> <td>1514</td> <td>1561</td> <td>1608</td> <td>1659</td> <td>1/11</td> <td>1778</td> <td></td> <td></td> <td></td>		3 TCH/V 012			Speed (RPM)	-	1469	1514	1561	1608	1659	1/11	1778			
2 Allnow (ns) 105 156 151 143 138 131 125 116 110 Speed (RPM) 1364 1413 1467 1522 1582 1644 1707 1767 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (l/s) 142 134 126 118 110<	TCH/V 012		144	104	Power (VV)	-	84	87	89	92	95	98	102	44.0	440	
Z Speed (N-M) 1304 1413 1407 1322 1382 1044 1707 1719 1819 Power (W) 67 69 72 74 77 80 84 87 89 Airflow (I/s) 142 134 126 118 110 56					Alfilow (I/S)		100	100	1/167	145	1582	1644	120	1767	1910	
Airflow (l/s) 142 134 126 118 110		2			Power (M/)		67	60	72	7/	77	80	8/	87	80	
Ainow (#5) 142 134 120 110 110			-				1/2	13/	126	118	110	00	04	07	09	
1 Speed (RPM) 1205 1264 1328 1393 1469	1			Speed (RPM)		1205	1264	1328	1393	1469						
Power (M) 46 49 51 53 56				Power (W)		46	49	51	53	56						

Black areas denote ESP where operation is not recommended.

Units factory shipped on speeds 2 and 1 for sizes 06-12; 3 and 2 for sizes 15-60. Other speeds require field selection.

All airflow is rated and shown above at the lower voltage.

Performance stated is at the rated power supply, performance may vary as the power supply varies from the rated.

ECM Motor – Blower Performance Data – High Static Units

	Fan	Rated	Min					Exte	rnal Sta	tic Pres	sure (Pa	a.)			
Model	Speed	Airflow (I/s)	Airflow (I/s)		0	25	50	75	100	125	150	175	200	225	250
				Airflow (l/s)		297	281	275	254	241	228				
	5			Speed (RPM)		918	942	974	1066	1114	1159	-			
		-		Airflow (I/s)	-	274	260	248	220	125	130	176	1		
	4			Speed (RPM)		862	884	953	1025	1074	1134	1202			
				Power (W)		87	89	95	102	106	112	118	-		
				Airflow (I/s)		250	240	220	205	188	164	146			
015	3	192	142	Speed (RPM)	-	805	831	930	984	1043	1119	1173	-		
		_		Power (W)		72	74	81	86	91	97	101			
				Airflow (I/s)		237	227	205	190	165	146	-			
	2			Speed (RPM)	-	62	814	904	961	1030	1100	-			
				Airflow (I/s)	-	221	205	186	168	142	00				
	1			Speed (RPM)	-	725	803	875	940	1022	-				
				Power (W)		54	59	64	68	74					
				Airflow (I/s)		322	309	303	282	267					
	5			Speed (RPM)	-	1016	1034	1070	1160	1209	-				
				Power (W)		302	201	116	125	129	232				
	4			Speed (RPM)		969	989	1043	1130	1174	1211	-			
				Power (W)	-	95	96	101	109	113	116	-			
				Airflow (I/s)		291	281	266	247	234	219	-			
TCH/V 018	3	230	178	Speed (RPM)		937	969	1031	1101	1148	1193	-			
		-		Power (W)	-	86	88	94	100	104	108	-			
	2			Speed (RPM)		264	253	995	1046	201	1158	-			
				Power (W)		66	70	76	80	84	88	-			
				Airflow (I/s)		243	229	208	192		ļ				
	1			Speed (RPM)		801	867	949	1003						
				Power (W)		54	58	64	67						
	-			Airflow (I/s)		413	394	377	363	348	328	301	278	-	
	5			Speed (RPM)		130	894	932	977	1024	1082	1156	1207	-	
				Airflow (I/s)		378	362	346	330	312	286	259	246	-	
	4			Speed (RPM)		808	850	893	938	992	1068	1129	1161	-	
				Power (W)		117	123	128	134	141	151	159	163		
				Airflow (I/s)		351	334	318	302	277	246	-			
TCH/V 024	3	274	234	Speed (RPM)		767	808	854	903	977	1052	-			
024		-		Power (W)	-	99	104	109	115	123	132				
				Airflow (I/s)		335	316	297	275	239	-				
	2			Bower (W/)		83	88	019	101	975	-				
	<u> </u>	1		Airflow (I/s)		307	288	269	237	110					
	1			Speed (RPM)		693	740	796	881	-					
	· ·			Power (W)		71	76	81	89						
				Airflow (I/s)		481	471	457	444	432	419	407			
	5			Speed (RPM)		934	979	1028	1073	1110	1144	1182	-		
				Power (W)		195	204	213	221	228	235	243			
				Airflow (I/s)		443	429	414	401	388	373	357			
	4			Speed (RPM)		868	914	964	1004	1048	1092	1145	-		
	L	1		Power (W)		155	163	171	177	184	191	199			
TCH/V				Airflow (I/s)		405	390	375	356	345	328	303			
030	3	343	295	Speed (RPM)		806	859	909	953	1006	1061	1132			
		-		Airflow (W)		357	340	138	144	151	159	801			
	2			Speed (PDM)		7/0	940 806	920	000						
	<u> </u>			Power (W)		96	103	100	115						
		1		Airflow (I/s)		341	323	306	110						
	1			Speed (RPM)		710	768	822							
				Power (W)		80	86	92							

Black areas denote ESP where operation is not recommended.

Units factory shipped on speeds 2 and 1 for sizes 06-12; 3 and 2 for sizes 15-60. Other speeds require field selection.

All airflow is rated and shown above at the lower voltage.

Performance stated is at the rated power supply, performance may vary as the power supply varies from the rated.

Table Continued on Next Page

ECM Motor – Blower Performance Data – High Static Units, Cont'd.

Airflow in I/	s with wet o	coil and clea	an air filter												
Model	Fan	Rated Airflow	Min Airflow					Exte	rnal Sta	tic Pres	sure (Pa	a.)			
	Speed	(l/s)	(l/s)		0	25	50	75	100	125	150	175	200	225	250
				Airflow (I/s)		574	561	546	533	518	503				
	5			Speed (RPM)		939	983	1033	1079	1122	1169				
		-		Airflow (I/s)		527	513	498	484	468	450	433			
	4			Speed (RPM)		877	926	979	1025	1071	1119	1167	-		
				Power (W)		213	224	234	244	254	264	274	-		
				Airflow (l/s)		484	468	452	435	416	399	379	354		
TCH/V	3	412	340	Speed (RPM)		824	879	932	981	1035	1082	1137	1197		
030	<u> </u>			Power (W)		167	177	187	196	205	213	222	233		
	2			Alfilow (I/S)		442	424	407	042	307	347	-			
	2			Power (W/)		132	828	1/0	942	995	1051	-			
	<u> </u>	1		Airflow (I/s)		300	379	357	150	100	175	L			
	1			Speed (RPM)		704	769	834	-						
	'					00	107	116	-						
				Airflow (I/s)		99 615	604	588	574	560					
	5			Speed (RPM)		1025	1063	1109	1161	1205					
				Power (W)		272	280	289	301	312					
		1		Airflow (I/s)		572	559	545	531	518	506				
	4			Speed (RPM)		977	1019	1072	1120	1161	1201	- ·			
	L	-		Power (W)		228	236	245	255	263	270	-			
TCH/V	3	490	444	AITTIOW (I/S)		038	521 985	1039	491	4/8	465	- 1			
042		480	411	Power (W)		197	204	213	221	228	235	-			
		1		Airflow (l/s)		481	465	450	436	421					
	2			Speed (RPM)		854	911	965	1011	1057					
		-		Power (W)		152	159	166	172	178					
				Airflow (I/s)		421	_								
	1			Speed (RPM)		790	-								
				Airflow (I/s)		768	745	722	698	674	653	628	500	577	
	5			Speed (RPM)		887	924	963	1006	1046	1081	1124	1167	1201	
				Power (W)		322	333	345	358	370	380	394	407	418	
		1		Airflow (l/s)		711	684	659	634	610	583	552	530	508	484
	4			Speed (RPM)		832	877	921	965	1006	1051	1098	1130	1166	1200
	L	-		Power (W)		266	278	289	300	311	323	336	344	354	364
тенли	2			Speed (PPM)		700	027	001	026	072	519 1010	494	-		
048	3	549	472	Power (W)		223	233	244	920 254	264	275	283			
		1		Airflow (I/s)		594	566	539	510	476	210	200			
	2			Speed (RPM)		738	787	835	883	934					
	-			Power (W)		182	192	201	210	220					
		1		Airflow (I/s)		538	508	478		1					
	1			Speed (RPM)		689	744	793	-						
				Power (W)		152	161	169	-						
				Airflow (l/s)		886	860	828	811	786	759	745	715	693	669
	5			Speed (RPM)		815	850	898	921	971	1010	1028	1083	1119	1215
		-		Power (W)		412	427	448	458	480	496	505	526	541	559
				Airflow (l/s)		831	812	781	762	735	711	692	664	639	
	4			Speed (RPM)		790	816	873	893	945	985	1003	1060	1102	
	L	-		Power (W)		353	363	390	393	418	436	440	465	481	
TCH/V	2	600	600	Airtiow (I/s)		800	700	740	721	043	055	070	01/		
060	3	000	000	Speed (KPM)		744	180	041 225	803	913	905	9/9	1038		
	L	-				30Z	704	000 602	660	6/7	617	307	400		
	2			Speed (RPM)		715	757	815	847	883	017				
	<u>_</u>			Power (W)		263	276	293	304	315	330				
		1		Airflow (l/s)		711	680	652	622	010					
	1			Speed (RPM)		686	732	789	828						
				Power (W)		230	242	257	268						

Table Continued from Previous Page

Black areas denote ESP where operation is not recommended.

Units factory shipped on speeds 2 and 1 for sizes 06-12; 3 and 2 for sizes 15-60. Other speeds require field selection.

All airflow is rated and shown above at the lower voltage.

Figure 22: AMV Valve Wiring



Figure 23: Taco SBV Valve Wiring



Electrical – Thermostat Wiring

Thermostat Installation

The thermostat should be located on an interior wall in a larger room, away from supply duct drafts. DO NOT locate the thermostat in areas subject to sunlight, drafts or on external walls. The wire access hole behind the thermostat may in certain cases need to be sealed to prevent erroneous temperature measurement. Position the thermostat back plate against the wall so that it appears level and so the thermostat wires protrude through the middle of the back plate. Mark the position of the back plate mounting holes and drill holes with a 3/16" (5mm) bit. Install supplied anchors and secure plate to the wall. Thermostat wire must be 18 AWG wire. Wire the appropriate thermostat as shown in Figure 25a to the low voltage terminal strip on the CXM2 or DXM2.5 control board. Practically any heat pump thermostat will work with ClimateMaster units, provided it has the correct number of heating and cooling stages.

Figure 25a: Units With PSC Fan And CXM2

Connection to CXM2 Control



Connection to DXM2.5 Control



TC- Horizontal – Dimensional Data

Horiz	ontal	0	verall Cabin	et
Mo	del	A Width	B Length	C Height
006 - 012	in	19.1	34.1	11.1
	cm	48.5	86.6	28.2
015 - 018	in	20.1	43.1	17.0
	cm	51.1	109.5	43.2
024 - 030	in	20.1	43.1	18.3
	cm	51.1	109.5	46.5
036 - 042	in	20.1	47.1	21.0
	cm	51.1	119.6	53.3
048 - 060	in	24.1	54.1	21.0
	cm	61.2	137.4	53.3

		Electrical Knockouts					
Horiz	ontal	J 1/2"	K 3/4"				
	uoi	Low Voltage	Power Supply				
006 - 012	in	5.1	2.1				
	cm	13.0	5.4				
015 - 018	in	9.9	6.9				
	cm	25.2	17.5				
024 - 030	in	11.1	8.1				
	cm	28.2	20.6				
036 - 060	in	13.9	10.9				
	cm	35.3	27.7				

				W	ater Connec	tions		
Horiz	ontal	(1	\mathbf{D}	(2)	(3)	Lean In/Out
Мо	del	Loop In D	Loop In E	Loop Out F	Loop Out G	AA	BB	FPT
006 - 012	in cm	5.6 14.2	1.1 2.7	1.6 4.1	1.1 2.7	3.3 8.4	0.7 1.8	1/2"
015	in cm	15.1 38.4	1.4 3.4	3.2 8.1	1.4 3.5	3.3 8.4	0.7 1.8	1/2"
018	in cm	15.1 38.4	1.4 3.4	4.1 10.4	1.4 3.5	3.3 8.4	0.7 1.8	1/2"
024	in cm	16.4 41.7	1.4 3.4	4.4 11.3	1.4 3.5	3.3 8.4	0.7 1.8	3/4"
030	in cm	16.4 41.7	1.4 3.4	3.1 7.8	1.4 3.5	3.3 8.4	0.7 1.8	3/4"
036	in cm	19.1 48.5	1.4 3.4	5.3 13.4	1.4 3.5	3.3 8.4	0.7 1.8	3/4"
042	in cm	19.1 48.5	1.4 3.4	4.4 11.3	1.4 3.5	3.3 8.4	0.7 1.8	3/4"
048	in cm	19.1 48.5	1.4 3.4	4.4 11.1	1.4 3.5	3.3 8.4	0.7 1.8	1"
060	in cm	19.1 48.5	1.4 3.4	3.8 9.7	1.4 3.5	3.3 8.4	0.7 1.8	1"

Discharge Connection Horizontal Duct Flange Installed (+/- 0.10 in, +/- 2.5mm)							Return Connection Using Return Air Opening					
Model		L	M Supply Height	N Supply Width	0	Р	Q Return Width	R Return Height	S	т		
006 - 012	in	0.8	8.9	6.7	6.0	1.3	16.1	9.8	1.1	0.6		
	cm	1.9	22.7	17.0	15.2	3.3	41.0	25.0	2.7	1.5		
015 - 018	in	2.6	13.3	9.9	4.1	1.3	23.0	15.0	1.1	1.0		
	cm	6.6	33.8	25.1	10.5	3.3	58.4	38.1	2.8	2.5		
024 - 030	in	2.6	13.3	9.9	4.1	1.3	23.0	16.3	1.1	1.0		
	cm	6.6	33.8	25.1	10.5	3.3	58.4	41.4	2.8	2.5		
036 - 042	in	2.5	16.1	11.0	3.0	2.5	25.9	19.0	1.1	1.0		
	cm	6.3	40.9	27.9	7.7	6.4	65.8	48.3	2.8	2.5		
048	in	3.7	16.1	13.7	4.1	1.3	35.9	19.0	1.1	1.0		
	cm	9.5	41.0	34.8	10.3	3.2	91.2	48.3	2.8	2.5		
060	in	1.7	18.1	13.7	4.1	1.3	35.9	19.0	1.1	1.0		
	cm	4.4	46.0	34.8	10.3	3.2	91.2	48.3	2.8	2.5		



TC - Horizontal - Dimensional Data, Cont'd.

Notes:

1. While clear access to all removable panels is not required, installer should take care to comply

with all building codes and allow adequate clearance for future field service.

2. Units are shipped with air filter rails that are not suitable for supporting return air ductwork. An air filter frame with duct mounting collar is available as an accessory, see the ClimateMaster Accessory Submittal set for futher information on this frame.

- 3. Discharge flange and hanger brackets are factory installed.
- 4. Condensate fitting on Polymer drain pan is rubber coupling that couples to 3/4" schedule 40/80 PVC, S.S. drain pan is 3/4" MPT.
- 5. Blower service panel requires 2' service access.
- 6. Blower service access is through back panel on straight discharge units or through panel opposite air coil on back discharge units.

Legend:

- CCP = Control/Compressor Access Panel.
- BSP = Blower Service Panel.
- *ASP = Additional Service Panel (not required).

Note

*ASP are removable panels that provide additional access to the units interior.

Clear access to ASP panels is not required and they are not to be used in place of the mandatory CCP and BSP panels.

TC - Vertical Upflow – Dimensional Data

Vertic	al	Overall Cabinet						
Upflo	w	A	B	C				
Mode	9l	Width	Depth	Height				
006 - 012	in	19.1	19.1	22.0				
	cm	48.5	48.5	55.9				
015 - 030,	in	21.5	21.5	40.0				
041	cm	54.6	54.6	101.6				
036 - 042	in	21.5	26.0	45.0				
	cm	54.6	66.0	114.3				
048 - 060	in	24.0	32.5	46.0				
	cm	61.0	82.6	116.8				

		Electrical Knockouts				
Vert	ical	J	K			
	Iel	1/2"	3/4"			
inio		Low Voltage	Power Supply			
006 - 012	in	5.9	8.9			
	cm	14.9	22.5			
015 - 060	in	7.1	10.1			
	cm	18.1	25.7			
041	in	7.1	11.1			
	cm	18.0	28.2			

			Wate	er Conne	ctions - S	Standard	Units	
Vert	ical	(D				3)	
Upfl Moo	ow del	Loop In D	Loop In E	Loop Out F	Loop Out G	н	I	Loop In/Out FPT
006 - 012	in cm	1.5 3.8	1.5 3.8	9.5 24.1	1.5 3.8	11.7 29.7	1.4 3.6	1/2"
015	in cm	1.9 4.8	1.4 3.6	13.8 35.1	1.4 3.6	19.7 50.0	1.4 3.6	1/2"
018	in cm	1.9 4.8	1.4 3.6	13.8 35.1	1.4 3.6	19.7 50.0	1.4 3.6	1/2"
024	in cm	1.9 4.8	1.4 3.6	13.8 35.1	1.4 3.6	19.7 50.0	1.4 3.6	3/4"
030	in cm	1.9 4.8	1.4 3.6	15.2 38.6	1.4 3.6	19.7 50.0	1.4 3.6	3/4"
036	in cm	1.9 4.8	1.4 3.6	15.2 38.6	1.4 3.6	20.6 52.3	1.4 3.6	3/4"
041	in cm	3.6 4.8	2.3 5.8	14.0 35.6	2.3 5.8	18.3 46.5	2.3 5.8	3/4"
042	in cm	1.9 4.8	1.4 3.6	16.6 42.0	1.4 3.6	20.6 52.3	1.4 3.6	3/4"
048	in cm	2.0 5.1	1.4 3.6	16.9 42.9	1.4 3.6	21.6 54.9	1.4 3.6	1"
060	in cm	2.0 5.1	1.4 3.6	17.4 44.2	1.4 3.6	21.6 54.9	1.4 3.6	1"

CCP = Control/Compressor Access Panel

BSP = Blower Service Panel

ASP = Alternative Service Panel

Notes:

- 1. While clear access to all removable panels is not required, installer should take care to comply with all building codes and allow adequate clearance for future field service.
- Front & Side access is preferred for service access. However, all components may be serviced from the front access panel if side access is not available. (Except on TCV 009-030 and 041 with front return) Units with the front return require left side access for the fan.
- 3. Discharge flange is field installed.
- Condensate fitting on Polymer drain pan is rubber coupling that couples to ¾" schedule 40/80 PVC, S.S. drain pan is 3/4" MPT.
- 5. Units are shipped with air filter rails that are not suitable for supporting return air ductwork. An air filter frame with duct mounting collar is available as an accessory, see the ClimateMaster Accessory Submittal set for futher information on this frame.

Rec	Recommended Minimum Installation Clearances for Vertical Units*								
1"	Back of unit								
Ľ	Side opposite return air								
6"	Front if hard piped								
Return Air Side									
	Ducted return								
1"	- ‡ *Add for duct width								
	- † Add 2" for 1" filter frame/rail or 3" for 2" filter frame/rail								
	Free (open) return - calculate required dimension for a maximum velocity of 600 fpm								

*Field installed accessories (hoses, air cleaners, etc.) and factory WSE option will require additional space. Top supply air is shown, the same clearances apply to bottom supply air units.



Legend:

TCV - Vertical Upflow – Dimensional Data, Cont'd.

Vertical Model		Duct	Disch Flange Inst	arge Conne alled (+/- 0.	ection 10 in, +/- 2.	Return Connection Using Return Air Opening				
		М	N	O Supply Width	P Supply Depth	Q	R	S Return Depth	T Return Height	U
006 - 012	in	8.9	5.1	9.0	9.0	5.5	2.1	16.2	9.9	0.7
	cm	22.7	12.9	22.9	22.9	14.0	5.3	41.1	25.1	1.9
015 - 018	in	6.4	3.8	14.0	14.0	5.3	2.3	18.3	20.9	0.7
	cm	16.1	9.5	35.6	35.6	13.6	5.8	46.5	53.1	1.9
024 - 030	in	6.4	5.0	14.0	14.0	5.8	2.0	18.5	19.3	0.9
	cm	16.3	12.7	35.6	35.6	14.7	5.1	47.0	49.0	2.3
036 - 042	in	6.4	3.8	14.0	14.0	5.1	2.3	22.8	23.9	0.7
	cm	16.1	9.5	35.6	35.6	13.1	5.8	57.9	60.7	1.9
048 - 060	in	6.9	7.3	16.0	18.0	5.1	2.3	29.3	22.5	0.7
	cm	17.4	18.4	40.6	45.7	13.1	5.8	74.4	57.0	1.9

Front Return - N = 4.8 in (12.2 cm), Q = 6.4 in (16.3 cm). Right Return - N = 3.8 in (9.7 cm), Q = 5.5 in (14.0 cm). Left Return - M = 6.4 in (16.3 cm), N = 2.8 in (7.1 cm).



Units are shipped with air filter rails that are not suitable for supporting return air ductwork. An air filter frame with duct mounting collar is available as an accessory, see the ClimateMaster Accessory Submittal set for further information on this frame.

TC Series Wiring Diagram Matrix

All current diagrams can be located online at climatemaster.com. Click 'Commercial Professional'.

- 1. Click 'Products' in the main navigation
- 2. Select 'Small Packaged Units'
- 3. Select the TC product series
- 4. Click the Wire Diagrams tab in the middle of the page
- 5. Select your voltage and controls

	DIGITS				V	U
WIRE DIAGRAMS	9	12	14	TC006. 009.012	TC015.018. 024.030.036	TC0030.036. 042.048.060
CXM2 - 50 HZ	F	A.C.J.N	TROVVZ	96B0514N41 96		96B0514N51
DXM2.5 - 50 HZ	G		1.B.S.V.Y.Z	96B0514N42		96B0514N52
Auxiliary WD for MPC	T, U	-	-	96B0147N14		4
Control Box Layouts		-	-	96B0500N00		0

Unit Controllor	Ean Matar	220-240/50/1	380-420/50/3	
Unit Controller	Fail Wotor	006-036	030-060	
CYM2	PSC	96B0514N41	96B0514N51	
CXM2	CT ECM	96B0514N42	96B0514N52	
DYM2 5	PSC	96B0480N12	96B0480N22	
DAWI2.5	CT ECM	96B0228N93	96B0230N64	
Auxiliary WD fo	or MPC Controls	96B01	47N14	

Controls – CXM2 and DXM2.5



CXM2 Controls

For detailed controller information, see the CXM2 Application, Operation, and Maintenance (AOM) manual (part # 97B0137N01). To confirm the controller type of your particular unit, refer to digit 9 on the unit model number and the unit nomenclature diagram found on page 3 of this manual.



DXM2.5 Controls

For detailed controller information, see the DXM2.5 Application, Operation, and Maintenance (AOM) manual (part # 97B0142N01). To confirm the controller type of your particular unit, refer to digit 9 on the unit model number and the unit nomenclature diagram found on page 3 of this manual.

Operating Limits

Operating Conditions

Environment – Units are designed for indoor installation only. Never install units in areas subject to freezing or where humidity levels could cause cabinet condensation (such as unconditioned spaces subject to 100% outside air).

Power Supply – A voltage variation of +/– 10% of nameplate utilization voltage is acceptable.

Determination of operating limits is dependent primarily upon three factors: 1) return air temperature. 2) water temperature, and 3) ambient temperature. When any one of these factors is at minimum or maximum levels, the other two factors should be at normal levels to ensure proper unit operation. Extreme variations in temperature and humidity and/or corrosive water or air will adversely affect unit performance, reliability, and service life. Consult Table 9a for operating limits.

Comissioning Conditions

Starting conditions are based upon the following notes:

Notes:

- Conditions in Table 9b are not normal or continuous operating conditions. Minimum/maximum limits are start-up conditions to bring the building space up to occupancy temperatures. Units are not designed to operate under these conditions on a regular basis.
- 2. Voltage utilization range complies with AHRI Standard 110.

Table 9a: Operating Limits

	Т	C	
	Cooling	Heating	
Air Limits			
Min. ambient air, DB	7°C	4°C	
Rated ambient air, DB	27°C	20°C	
Max. ambient air, DB	43°C	29°C	
Min. entering air, DB/WB	18/10°C	7.2°C	
Rated entering air, DB/WB	27/19°C	20°C	
Max. entering air, DB/WB	35/24°C	27°C	
Water Limits			
Min. entering water	-1°C	-6.7°C	
Normal entering water	10-43°C	-1 to 21°C	
Max. entering water	49°C	32°C	
Normal Water Flow	1.6 to 3.2 l/m per kW		
Maximum Altitude	304	8 m	

Table 9b: Commissioning Limits

	Т	C	
	Cooling	Heating	
Air Limits			
Min. ambient air, DB	7°C	4°C	
Rated ambient air, DB	27°C	20°C	
Max. ambient air, DB	43°C	29°C	
Min. entering air, DB/WB	10/7°C	4.5°C	
Rated entering air, DB/WB	27/19°C	20°C	
Max. entering air, DB/WB	43/28°C	27°C	
Water Limits			
Min. entering water	-1°C	-6.7°C	
Normal entering water	10-43°C	-1 to 21°C	
Max. entering water	49°C	32°C	
Normal Water Flow	1.6 to 3.2 l/m per kW		
Maximum Altitude	3048 m		

Piping System Cleaning and Flushing

Piping System Cleaning and Flushing - Cleaning and flushing the WLHP piping system is the single most important step to ensure proper start-up and continued efficient operation of the system.

Follow the instructions below to properly clean and flush the system:

- 1. Ensure that electrical power to the unit is disconnected.
- 2. Install the system with the supply hose connected directly to the return riser valve. Use a single length of flexible hose.
- 3. Open all air vents. Fill the system with water. DO NOT allow system to overflow. Bleed all air from the system Pressurize and check the system for leaks and repair as appropriate. ClimaDry®-equipped units have a manual air bleed valve at the top of the reheat coil. This valve must be used to bleed the air from the reheat coil after filling the system, for ClimaDry[®] to operate properly.
- 4. Verify that all strainers are in place (ClimateMaster recommends a strainer with a #20 stainless steel wire mesh). Start the pumps, and systematically check each vent to ensure that all air is bled from the system.
- 5. Verify that make-up water is available. Adjust make-up water as required to replace the air which was bled from the system. Check and adjust the water/air level in the expansion tank.
- 6. Set the boiler to raise the loop temperature to approximately 30°C. Open a drain at the lowest point in the system. Adjust the make-up water replacement rate to equal the rate of bleed.
- Refill the system and add trisodium phosphate in a proportion of approximately 1/2 kg per 750 l of water (or other equivalent approved cleaning agent). Reset the boiler to raise the loop temperature to 38°C. Circulate the solution for a minimum of 8 to 24 hours. At the end of this period, shut off the circulating pump and drain the solution. Repeat system cleaning if desired.
- 8. When the cleaning process is complete, remove the short-circuited hoses. Reconnect the hoses to the proper supply, and return the connections to each of the units. Refill the system and bleed off all air.
- 9. Test the system pH with litmus paper. The system water should be in the range of pH 6.0 8.5 (see table 3). Add chemicals, as appropriate to maintain neutral pH levels.
- 10. When the system is successfully cleaned, flushed, refilled and bled, check the main system panels, safety cutouts and alarms. Set the controls to properly maintain loop temperatures

CAUTION! 🦊

DO NOT use "Stop Leak" or similar chemical agent in this system. Addition of chemicals of this type to the loop water will foul the heat exchanger and inhibit unit operation.

CAUTION! 🥼

Note: The manufacturer strongly recommends all piping connections, both internal and external to the unit, be pressure tested by an appropriate method prior to any finishing of the interior space or before access to all connections is limited. Test pressure may not exceed the maximum allowable pressure for the unit and all components within the water system. The manufacturer will not be responsible or liable for damages from water leaks due to inadequate or lack of a pressurized leak test, or damages caused by exceeding the maximum pressure rating during installation.

Unit Starting and Operating Conditions

WARNING!

WARNING! Polyolester Oil, commonly known as POE oil, is a synthetic oil used in many refrigeration systems including those with HFC-410A refrigerant. POE oil, if it ever comes in contact with PVC or CPVC piping, may cause failure of the PVC/CPVC. PVC/CPVC piping should never be used as supply or return water piping with water source heat pump products containing HFC-410A as system failures and property damage may result.

Unit and System Checkout

BEFORE POWERING SYSTEM, please check the following:

UNIT CHECKOUT

- Balancing/shutoff valves: Ensure that all isolation valves are open and water control valves are wired.
- Line voltage and wiring: Verify that voltage is within an acceptable range for the unit and wiring and fuses/breakers are properly sized. Verify that low voltage wiring is complete.
- <u>Unit control transformer</u>: Ensure that transformer has the properly selected voltage tap.
- Entering water and air: Ensure that entering water and air temperatures are within operating limits of Table 8a-b.
- □ <u>Low water temperature cutout:</u> Verify that low water temperature cut-out on the CXM2/DXM2.5 control is properly set.
- Unit fan: Manually rotate fan to verify free rotation and ensure that blower wheel is secured to the motor shaft. Be sure to remove any shipping supports if needed. DO NOT oil motors upon startup. Fan motors are pre-oiled at the factory. Check unit fan speed selection and compare to design requirements.
- <u>Condensate line:</u> Verify that condensate line is open and properly pitched toward drain.
- Water flow balancing: Record inlet and outlet water temperatures for each heat pump upon startup. This check can eliminate nuisance trip outs and high velocity water flow that could erode heat exchangers.
- Unit air coil and filters: Ensure that filter is clean and accessible. Clean air coil of all manufacturing oils.
- Unit controls: Verify that CXM2 or DXM2.5 field selection options are properly set.

SYSTEM CHECKOUT

- <u>System water temperature:</u> Check water temperature for proper range and also verify heating and cooling setpoints for proper operation.
- System pH: Check and adjust water pH if necessary to maintain a level between 6 and 8.5. Proper pH promotes longevity of hoses and fittings (see table 3).
- System flushing: Verify that all hoses are connected end to end when flushing to ensure that debris bypasses the unit heat exchanger, water valves and other components. Water used in the system must be potable quality initially and clean of dirt, piping slag, and strong chemical cleaning agents. Verify that all air is purged from the system. Air in the system can cause poor operation or system corrosion.
- <u>Cooling tower/boiler:</u> Check equipment for proper setpoints and operation.
- □ <u>Standby pumps:</u> Verify that the standby pump is properly installed and in operating condition.
- <u>System controls:</u> Verify that system controls function and operate in the proper sequence.
- Low water temperature cutout: Verify that low water temperature cut-out controls are provided for the outdoor portion of the loop. Otherwise, operating problems may occur.
- System control center: Verify that the control center and alarm panel have appropriate setpoints and are operating as designed.
- Miscellaneous: Note any questionable aspects of the installation.

CAUTION!

CAUTION! Verify that ALL water control valves are open and allow water flow prior to engaging the compressor. Freezing of the coax or water lines can permanently damage the heat pump.

CAUTION!

CAUTION! To avoid equipment damage, DO NOT leave system filled in a building without heat during the winter unless antifreeze is added to the water loop. Heat exchangers never fully drain by themselves and will freeze unless winterized with antifreeze.

Unit Start-up Procedure

- 1. Turn the thermostat fan position to "ON". Blower should start.
- 2. Balance air flow at registers.
- 3. Adjust all valves to their full open positions. Turn on the line power to all heat pumps.
- 4. Room temperature should be within the minimummaximum ranges of table 9. During start-up checks, loop water temperature entering the heat pump should be between 16°C and 35°C.
- 5. Two factors determine the operating limits of ClimateMaster heat pumps, (a) return air temperature, and (b) water temperature. When any one of these factors is at a minimum or maximum level, the other factor must be at normal level to insure proper unit operation.
 - a. Adjust the unit thermostat to the warmest setting. Place the thermostat mode switch in the "COOL" position. Slowly reduce thermostat setting until the compressor activates.
 - b. Check for cool air delivery at the unit grille within a few minutes after the unit has begun to operate. Note: Units have a five minute time delay in the control circuit that can be eliminated on the CXM2/ DXM2.5 control board as shown below in Figure 28. See controls description for details.
 - c. Verify that the compressor is on and that the water flow rate is correct by measuring pressure drop through the heat exchanger using the P/T plugs and comparing to table 10.
 - d. Check the elevation and cleanliness of the condensate lines. Dripping may be a sign of a blocked line. Check that the condensate trap is filled to provide a water seal.
 - e. Refer to table 17. Check the temperature of both entering and leaving water. If temperature is within range, proceed with the test. Verify correct water flow by comparing unit pressure drop across the heat exchanger versus the data in tables 10b and c. Heat of rejection (HR) can be calculated and compared to submittal data capacity pages. The formula for HR for systems with water is as follows: HR (kW) = TD x I/s x 4.18,where TD is the the temperature difference of the temperature of tempe

temperature difference between the entering and leaving water, and I/s is the flow rate, determined by comparing the pressure drop across the heat exchanger to table 10.

- f. Check air temperature drop across the air coil when compressor is operating. Air temperature drop should be between 8°C and 14°C.
- g. Turn thermostat to "OFF" position. A hissing noise indicates proper functioning of the reversing valve.
- 6. Allow five (5) minutes between tests for pressure to equalize before beginning heating test.
 - Adjust the thermostat to the lowest setting.
 Place the thermostat mode switch in the "HEAT" position.
 - b. Slowly raise the thermostat to a higher temperature until the compressor activates.

Unit Start-Up Procedure

- c. Check for warm air delivery within a few minutes after the unit has begun to operate.
- d. Refer to table 17. Check the temperature of both entering and leaving water. If temperature is within range, proceed with the test. Verify correct water flow by comparing unit pressure drop across the heat exchanger versus the data in table 10. Heat of extraction (HE) can be calculated and compared to submittal data capacity pages. The formula for HE for systems with water is as follows:

HE (kW) = TD x l/s x 4.18, where TD is the temperature difference between the entering and leaving water, and l/s is the flow rate in U.S. GPM, determined by comparing the pressure drop across the heat exchanger to table 10.

- e. Check air temperature rise across the air coil when compressor is operating. Air temperature rise should be between 11°C and 17°C.
- f. Check for vibration, noise, and water leaks.
- If unit fails to operate, perform troubleshooting analysis (see troubleshooting section). If the check described fails to reveal the problem and the unit still does not operate, contact a trained service technician to insure proper diagnosis and repair of the equipment.
- 8. When testing is complete, set system to maintain desired comfort level.
- 9. BE CERTAIN TO FILL OUT AND FORWARD ALL WARRANTY REGISTRATION PAPERS TO CLIMATEMASTER.

Note: If performance during any mode appears abnormal, refer to the CXM2/DXM2.5 section or troubleshooting section of this manual. To obtain maximum performance, the air coil should be cleaned before start-up. A 10% solution of dishwasher detergent and water is recommended.

Figure 28: Test Mode Button



CAUTION! Verify that ALL water control valves are open and allow water flow prior to engaging the compressor. Freezing of the coax or water lines can permanently damage the heat pump.

CLIMATEMASTER WATER-SOURCE HEAT PUMPS

Tranquility 16 (TC) Series Rev.: 24 January, 2023

Table 10: TC Coax Water Pressure Drop

Madal	1/e	Pressure Drop, kPa								
Model	1/5	-1°C	10°C	21°C	32°C					
	0.05	3.7	2.3	1.6	1.6					
006	0.07	5.3	3.5	2.7	2.2					
	0.09	8.8	6.1	4.8	4.0					
	0.07	9.0	4.4	2.8	1.9					
009	0.11	14.1	9.4	7.4	6.2					
	0.14	24.3	17.9	14.7	12.7					
	0.09	12.8	7.6	5.3	4.1					
012	0.15	25.0	17.8	14.3	12.1					
	0.19	46.1	34.3	28.3	24.5					
	0.12	6.9	4.4	3.4	2.8					
015	0.18	12.4	9.3	7.6	6.9					
	0.24	22.7	17.5	14.7	13.1					
	0.14	14.5	9.9	7.6	6.2					
018	0.21	23.4	17.6	14.7	12.4					
	0.28	40.6	31.5	26.9	23.4					
	0.19	15.2	11.6	9.6	8.3					
024	0.28	27.6	22.2	19.3	17.2					
	0.38	49.6	40.6	35.8	32.4					
	0.24	9.0	6.1	4.8	4.1					
030	0.35	15.8	12.5	10.3	9.6					
	0.47	28.9	23.2	20	17.9					
	0.28	12.4	9.6	8.3	6.9					
036	0.43	21.4	16.8	14.7	13.1					
	0.57	37.2	30.0	26.2	23.4					
	0.33	15.8	12.1	10.3	9.0					
042	0.50	29.6	24.2	26.4	19.3					
	0.66	54.4	44.8	39.3	35.8					
	.038	12.4	10.1	9.0	8.3					
048	0.57	23.4	20.4	18.6	17.9					
	0.76	42.7	37.9	35.1	35.1					
	0.47	23.4	19.2	16.5	15.2					
060	0.71	46.9	40.8	37.2	34.5					
	0.95	86.8	76.8	71.0	66.1					

Table 17: Water Temperature Change Through Heat Exchanger

Water Flow, I/m	Rise, Cooling °C	Drop, Heating °C
For Closed Loop: Ground Source or Closed Loop Systems at 3.2 I/m per kW	5 - 6.7	2.2 - 4.4
For Open Loop: Ground Water Systems at 1.6 I/m per kW	11.1 - 14.4	5.6 - 9.4

Preventive Maintenance

Water Coil Maintenance

(Direct ground water applications only)

If the system is installed in an area with a known high mineral content (125 P.P.M. or greater) in the water, it is best to establish a periodic maintenance schedule with the owner so the coil can be checked regularly. Consult the well water applications section of this manual for a more detailed water coil material selection. Should periodic coil cleaning be necessary, use standard coil cleaning procedures, which are compatible with the heat exchanger material and copper water lines. Generally, the more water flowing through the unit, the less chance for scaling. Therefore, 1.6 l/m per kW is recommended as a minimum flow. Minimum flow rate for entering water temperatures below 10°C is 2.2 l/m per kW.

Water Coil Maintenance

(All other water loop applications)

Generally water coil maintenance is not needed for closed loop systems. However, if the piping is known to have high dirt or debris content, it is best to establish a periodic maintenance schedule with the owner so the water coil can be checked regularly. Dirty installations are typically the result of deterioration of iron or galvanized piping or components in the system. Open cooling towers requiring heavy chemical treatment and mineral buildup through water use can also contribute to higher maintenance. Should periodic coil cleaning be necessary, use standard coil cleaning procedures, which are compatible with both the heat exchanger material and copper water lines. Generally, the more water flowing through the unit, the less chance for scaling. However, flow rates over 3.9 l/m per kW can produce water (or debris) velocities that can erode the heat exchanger wall and ultimately produce leaks.

Filters

Filters must be clean to obtain maximum performance. Filters should be inspected every month under normal operating conditions and be replaced when necessary. Units should never be operated without a filter.

Washable, high efficiency, electrostatic filters, when dirty, can exhibit a very high pressure drop for the fan motor and reduce air flow, resulting in poor performance. It is especially important to provide consistent washing of these filters (in the opposite direction of the normal air flow) once per month using a high pressure wash similar to those found at self-serve car washes.

Condensate Drain

In areas where airborne bacteria may produce a "slimy" substance in the drain pan, it may be necessary to treat the drain pan chemically with an algaecide approximately every three months to minimize the problem. The condensate pan may also need to be cleaned periodically to insure indoor air quality. The condensate drain can pick up lint and dirt, especially with dirty filters. Inspect the drain twice a year to avoid the possibility of plugging and eventual overflow.

Compressor

Conduct annual amperage checks to insure that amp draw is no more than 10% greater than indicated on the serial plate data.

Fan Motors

All units have lubricated fan motors. Fan motors should never be lubricated unless obvious, dry operation is suspected. Periodic maintenance oiling is not recommended, as it will result in dirt accumulating in the excess oil and cause eventual motor failure. Conduct annual dry operation check and amperage check to insure amp draw is no more than 10% greater than indicated on serial plate data.

Air Coil

The air coil must be cleaned to obtain maximum performance. Check once a year under normal operating conditions and, if dirty, brush or vacuum clean. Care must be taken not to damage the aluminum fins while cleaning. **CAUTION: Fin edges are sharp.**

Cabinet

Do not allow water to stay in contact with the cabinet for long periods of time to prevent corrosion of the cabinet sheet metal. Generally, vertical cabinets are set up from the floor 7 - 8 cm to prevent water from entering the cabinet. The cabinet can be cleaned using a mild detergent.

Refrigerant System

To maintain sealed circuit integrity, do not install service gauges unless unit operation appears abnormal. Reference the operating charts for pressures and temperatures. Verify that air and water flow rates are at proper levels before servicing the refrigerant circuit.

📐 CAUTION! 🕂

CAUTION! Many units are installed with a factory or field supplied manual or electric shut-off valve. DAMAGE WILL OCCUR if shut-off valve is closed during unit operation. A high pressure switch must be installed on the heat pump side of any field provided shut-off valves and connected to the heat pump controls in series with the built-in refrigerant circuit high pressure switch to disable compressor operation if water pressure exceeds pressure switch setting. The field installed high pressure switch shall have a cut-out pressure of 300 psig and a cut-in pressure of 250 psig.

Functional Troubleshooting

Fault	Htg	Clg	Possible Cause	Solution
		1		Check line voltage circuit breaker and disconnect.
				Check for line voltage between L1 and L2 on the contactor.
Main power problems	X	х	Green Status LED Off	Check for 24VAC between R and C on CXM2/DXM2.5'
				Check primary/secondary voltage on transformer.
-	İ	İ		Check pump operation or valve operation/setting.
		X	Reduced or no water flow in cooling	Check water flow adjust to proper flow rate.
		X	Water Temperature out of range in cooling	Bring water temp within design parameters.
				Check for dirty air filter and clean or replace.
Code 2				Check fan motor operation and airflow restrictions.
00002	X		Reduced or no air flow in heating	Dirty Air Coil- construction dust etc.
High Pressure				Too high of external static. Check static vs blower table.
	X		Air temperature out of range in heating	Bring return air temp within design parameters.
	x	x	Overcharged with refrigerant	Check superheat/subcooling vs typical operating condition table.
	х	x	Bad HP Switch	Check switch continuity and operation, Replace.
LP/LOC Fault	X	X	Insufficient charge	Check for refrigerant leaks
Code 3			5	
	X		Compressor pump down at start-up	Check charge and start-up water flow.
Low Pressure / Loss of Charge	<u> </u>			
				Check pump operation or water valve operation/setting.
LT1 Foult	X	X Reduced or no water flow in heating Plugged strainer or filter. Clean or replace		Plugged strainer or filter. Clean or replace.
Code 4				Check water flow adjust to proper flow rate.
00004	X		Inadequate antifreeze level	Check antifreeze density with hydrometer.
Water coil low	x		Improper temperature limit setting (30°F vs	Clip JW3 jumper for antifreeze (10°F [-12°C]) use.
temperature limit		-	иг[-1 U vs -2 ⁻ U]) Water Temperature	Pring water terms within dealer
	\vdash_{\vee}^{\times}		vvaler remperature out of range	Check temp and impedance and imp
	X	X	bad inermistor	Check temp and impedance correlation per chart
			Deduced energy ()	Oheck for dirty air liller and clean or replace.
LT2 Fault		X	Reduced or no air flow in cooling	Check fan motor operation and airflow restrictions.
Code 5	<u> </u>	<u> </u>		Too high of external static. Check static vs blower table.
Air coil low		X	Air Temperature out of range	Too much cold vent air? Bring entering air temp within design parameters.
temperature limit		X	Improper temperature limit setting (30°F vs	Normal airside applications will require 30°F [-1°C] only.
		v	Red thermister	Check town and impedance correlation per chart
			Plackad drain	Check fee blockage and alege drain
				Check for blockage and clean drain.
	<u> </u>		Improper trap	Check trap dimensions and location ahead of vent.
				Check for piping slope away from unit.
Condensate Fault		X	Poor drainage	Check slope of unit toward outlet.
Code 6		N N		Poor venting. Check vent location.
		X	Moisture on sensor	Check for moisture shorting to air coil.
		X		
	X	X	Restricted Return Air Flow	Find and eliminate restriction. Increase return duct and/or grille size.
				Check power supply and 24VAC voltage before and during operation.
Over/Under	x	x	Under Voltage	Check power supply wire size.
Voltage Code 7				Check compressor starting. Need hard start kit?
(Auto resetting)				Check 24VAC and unit transformer tap for correct power supply voltage.
(Auto resetting)	x	x	Over Voltage	Check power supply voltage and 24VAC before and during operation.
	<u> </u>			Check 24VAC and unit transformer tap for correct power supply voltage.
Unit Performance Sentinel	X		Heating mode FP2>125°F [52°C]	Check for poor air flow or overcharged unit.
Code 8		X	Cooling Mode FP1>125°F [52°C] OR FP2<	Check for poor water flow, or air flow.
	v	v	No compressor operation	See "Only Fan Onerates"
No Fault Code Shows	$\stackrel{\wedge}{\lor}$			Check and replace if necessary
No Fault Code Snown	~		Compressor overroad	Depet never and shack exercise
	×		Dirty air filter	Reset power and check operation.
			Unity air liller	Direck and clean air filler.
Unit Short Cycles		X	Unit in "test mode"	Resei power or Walt 20 minutes for auto exit.
		X		Unit may be oversized for space. Check sizing for actual load of space.
	X		Compressor overload	Uneck and replace if necessary
	X	X	I nermostat position	Ensure thermostat set for heating or cooling operation.
		X	Unit locked out	Check for lockout codes. Reset power.
Uniy Fan Runs	⊢×_	⊢×	Compressor Overload	Check compressor overload. Replace if necessary.
	X	X	Thermostat wiring	Спеск tnermostat wiring at heat pump. Jumper Y and R for compressor operation
	X	X	Thermostat wiring	Check G wiring at heat pump. Jumper G and R for fan operation
	X	X	Fan motor relav	Jumper G and R for fan operation. Check for Line voltage across BR contacts.
Only Compressor Runs	Х	X	,	Check fan power enable relay operation (if present).
	X	X	Fan motor	Check for line voltage at motor. Check capacitor.
	x	x	Thermostat wiring	Check thermostat wiring at heat pump. Jumper Y and R for compressor operation
	<u> </u>	-	~	
				beard board board board board board board board board board
		X	Reversing valve	If RV is stuck run high pressure up by reducing water flow and while operating
				engage and disengage RV coil voltage to push valve.
Unit Doesn't Operate		X	Thermostat setup	Check for 'O' RV setup not 'B'.
in Cooling		X	Thermostat wiring	Check O wiring at heat pump. Jumper O and R for RV coil 'click'.
				Put thermostat in cooling mode. Check 24 VAC on O (check between C and
		x	Thermostat wiring	O); check for 24 VAC on W (check between W and C). There should be voltage on O, but not on W. If voltage is present on W, thermostat may be bad or wired
	l	1		l inconecuy.

Performance Troubleshooting

Symptom	Htg	Clg	Possible Cause	Solution
	X	X	Dirty filter	Replace or clean.
			-	Check for dirty air filter and clean or replace.
	x		Reduced or no airflow in heating	Check fan motor operation and airflow restrictions.
			-	Too high of external static? Check static vs blower table.
				Check for dirty air filter and clean or replace.
		х	Reduced or no airflow in cooling	Check fan motor operation and airflow restrictions.
			_	Too high of external static? Check static vs blower table.
Insufficient capacity/ Not	x	х	Leaky duct work	Check supply and return air temperatures at the unit and at distant duct registers if significantly different, duct leaks are present.
cooling of heating	X	Х	Low refrigerant charge	Check superheat and subcooling per chart.
	X	Х	Restricted metering device	Check superheat and subcooling per chart. Replace.
		Х	Defective reversing valve	Perform RV touch test.
	X	Х	Thermostat improperly located	Check location and for air drafts behind stat.
	x	х	Unit undersized	Recheck loads & sizing. Check sensible clg. load and heat pump capacity.
	X	Х	Scaling in water heat exchanger	Perform scaling check and clean if necessary.
	X	Х	Inlet water too hot or too cold	Check load, loop sizing, loop backfill, ground moisture.
				Check for dirty air filter and clean or replace.
	X		Reduced or no airflow in heating	Check fan motor operation and air flow restrictions.
				Too high of external static? Check static vs blower table.
		v	Reduced or no water flow in cooling	Check pump operation or valve operation/setting.
		^	Reduced of no water now in cooling	Check water flow. Adjust to proper flow rate.
High Head Pressure		Х	Inlet water too hot	Check load, loop sizing, loop backfill, ground moisture.
	X		Air temperature out of range in heating	Bring return air temperature within design parameters.
		Х	Scaling in water heat exchanger	Perform scaling check and clean if necessary.
	X	Х	Unit overcharged	Check superheat and subcooling. Re-weigh in charge.
	X	Х	Non-condensables in system	Vacuum system and re-weigh in charge.
	Х	Х	Restricted metering device	Check superheat and subcooling per chart. Replace.
				Check pump operation or water valve operation/setting.
	X		Reduced water flow in heating	Plugged strainer or filter? Clean or replace.
				Check water flow. Adjust to proper flow rate.
	X		Water temperature out of range	Bring water temperature within design parameters.
Low Suction Pressure				Check for dirty air filter and clean or replace.
		Х	Reduced airflow in cooling	Check fan motor operation and air flow restrictions.
				Too high of external static? Check static vs blower table.
		х	Air temperature out of range	Too much cold vent air? Bring entering air temperature within design parameters.
	X	Х	Insufficient charge	Check for refrigerant leaks.
Low Discharge Air	X		Too high of airflow	Check fan motor speed selection and airflow chart.
Temperature in Heating	X		Poor performance	See 'Insufficient Capacity'.
I link housed dites		Х	Too high of airflow	Check fan motor speed selection and airflow chart.
High humidity		х	Unit oversized	Recheck loads & sizing. Check sensible cooling load and heat pump capacity.

Functional Troubleshooting – S-I Units



Note: Never connect refrigerant gauges during startup procedures. Conduct water-side analysis using P/T ports to determine water flow and temperature difference. If water-side analysis shows poor performance, refrigerant troubleshooting may be required. Connect refrigerant gauges as a last resort.



Ω

LIMITED EXPRESS WARRANTY /LIMITATION OF REMEDIES AND LIABILITY (FOR INTERNATIONAL CLASS PRODUCTS)

Disclaimer: It is expressly understood that unless a statement is specifically identified as a warranty, statements made by Climate Master, Inc., a Delaware corporation, U. S. A. ("CM") or its representatives, relating to CM's products, whether oral, write or contained in any salicitature catalog, this or any other agreement or other materials, are not press warrants and do to from a part to the basis of

which are air complete air ement parts, replacement maintenance as follows: (1) All first; and, (2) Repair and replace material defects in materials and workmanship under normal use and months from date of shipment (from CM's factory), whichever comes GRANT OF LIMITED EXPRESS WARRANTY Warrants Compondues purchased and installed outside the United States of America ("U.S.A.") and Canada to be free from conditioning, heating or heat purpus built or sold by Morr Morr Morr (12) months from date of unit start-up or eighteen (18) not supplied under warranty, for miney (90) days from date of shipment (from factory).

replacement under CM's sixty (60) days after the failure of the part. If CM determines that a parts order qualifies for 1 All duties, taxes and other fees shall be paid by the ultimate user through the Representative. Narranty parts shall be furnished by CM if ordered through an authorized sales representative of CM ("Representative") within varranty, such parts shall be shipped freight prepaid to the Representative or the ultimate user, as requested by Representative. Warranty

varranty returned or if CM under replaced (60) days after the date of the request. If the defective part is not timely fumily fumily freight. The warranty on any part repaired or repla If requested by CM, all defective parts shall be returned to CM's factory in Oklahoma City, Oklahoma, U.S.A. freight and duty prepaid, not later than sixty (determines the part to not be defective or otherwise not to qualify under CM's Limited Express Warranty, CM shall invoice Customer the costs for the parts expires at the end of the original warranty period.

s warranty does not cover and does not apply to: (1) Air filters, fuses, refrigerant, fluids, oil; (2) Products relocated after initial installation; (3) Any portion or component of any system that is not supplied by CM, regardless of the cause of the failure usub proton or component; (4) Products on which the unit identification gas or labels have been removed or detects; (3) Products on they customer's statistication; seconders or which the unit identification gas or labels have been removed or detects; (a) Products on Why proton or component to fany system that is not supplied by CM, regardless of the fault: Products which the unit identification gas or labels have been removed or detects; (a) Funds on Why are of the rease rease of the rease of t or the retrigram creating (8) Mold, fungus or bacteria damages; (9) Products subjected to corresion or abraion; (10) Products, parts or components or accidentigram (12) Products which have been operated in a manner contrary to CM's printed instructions; (13) Products which have defects, damage application, installation, or use of CM's products or (14) Electricity or fuel costs, or any increases or unrealized asyngs in same, for any reason. (6) Pro of such This ' fire,

cost any covered by CM's Limited Express Warranty; (2) The art from the installation site to CM or of the return of or the associated labor to repair or replace the same, which is incurred as a result of a defective part cor art, or in obtaining and replacing the new or repaired part; (3) Transportation costs of the defective part part, or in obtaining of labor, refrigerant, materials or service incurred in diagnosis and removal of the defective pr part not covered by CM's Limited Express Warranty; or (4) The costs of normal maintenance. , refrigerant or other system components, diagnosis and removal of the defective p responsible for: (1) The cost of any fluids, is not CM

warranty, including e any warranty that is any such warrai not exclude any exist, does 1 Limitation: This Limited Express Warranty is given in lieu of all other warranties. If, notwithstanding the disclaimers contained berein, it is determined by a court or other qualified judicial body that other warranties e without limitation any express Warranty or any implied warranty of fitness for particular purpose and merchantability, shall be limited to the duration of the Limited Express Warranty. This Limited Express Warranty diameters and merchantability, shall be limited to the duration of the Limited Express Warranty. This Limited Express Warranty duration any not be excluded under applicable imperative law.

In the event of a breach of this Limited Express Warranty or any warranty that is mandatory under applicable importative law, CM will only be obligated at CM's option to either repair the failed part or unit or to furnish a new or rebuilt part or unit in echange for the part or unit which has failed. If after written notice to CM's factory in Oklahoma, U.S.A. of each defect, malfunction or other failure and a reasonable number of attempts by CM to correct the defect, malfunction or other failure and a reasonable number of attempts by CM to correct the defect, malfunction or other relative for its research part or unit or contractive defect, malfunction or other failure and a reasonable number of attempts by CM to correct the defect, malfunction or other relative failure and a reasonable number of attempts by CM to correct the defect, malfunction or other a PPLICABLE LAW. THIS READEDY IS THE SOLLE AND EXCLUSIVE REMEDY OF THE CUSTOMER AGAINST CM FOR BREACH OF CONTRACT, FOR THE BREACH OF ANY WARRANTY OR FOR CM'S NEGLIGENCE OR IN STRUCT LAW. THE BREACH OF ANY WARRANTY OR FOR CM'S NEGLIGENCE OR IN STRUCT LAW. THE BREACH OF ANY WARRANTY OR FOR CM'S NEGLIGENCE OR IN STRUCT LAW.

LIMITATION OF LIABILITY CM shall have no liability for a

CM shift have no liability for any standard rest of the start reason or is prevented to any ctert used as but not limited to: any war, divid mean territion or restrings, strikes, or work suppages, fire, fload, accident, allocation, for any reason or is prevented to any ctert used as but not limited to: any war, divid mean territion or restrings, strikes, or work suppages, fire, fload, accident, allocation, allocations, field, americation of abor, acts of food range other reason beyond the sole control of CM. TO THE FULLIEST EXTENT PERMITTED BY APPLICABLE LAW No SIBBLET TO THE INST EXTERCT. FOR EXERCIPTION ANY EXCLUDES ANY LLABILITY FOR LOSS OF FRONTEST, LOSS OF FRONTESS OR GOODWILL, CONSEQUENTIAL, INCIDENTIAL, SPECIAL, LUONTED, OR VIANCE, CM FINATECT, FOR BREACT FOR INAY EXPRESS OR INPLIED WARRANTY, OR IN TORT, WHETHER FOR CM'S NEGLIGENCE OR AS STRICT LLABILITY. Nothing in this Ageometric fineded to exclude Statistic predemption of the and.

OBTAINING WARRANTY PERFORMANCE Normally, the contractor or service organization w

warranty any CM recognized Representative. If assistance is required in obtaining contact owner. Should the installer be unavailable, who installed the products will provide warranty performance for the performance, write or call: the

Climate Master, Inc. • Customer Service • 7300 S.W. 44th Street • Oklahoma City, Oklahoma, U.S.A. 73179 • (405) 745-6000 • FAX (405) 745-6068

of consequential or incidental damages, so the foregoing exclusions and limitations limitation or exclusions Some countries do not allow limitations on how long an implied warranty lasts, or the limitation or ex legal rights, and you may also have other rights which vary from state to state and country to country. NOTE: S specific l

Please refer to the CM Installation, Operation and Maintenance Manual for operating and maintenance instructions

Created: 10/09

Tranquility 16 (TC) Series Rev.: 24 January, 2023

may not apply to you. This warranty gives you

Warranty

Notes:

Notes:

CLIMATEMASTER WATER-SOURCE HEAT PUMPS

Tranquility 16 (TC) Series Rev.: 24 January, 2023

Revision History

Date	Item	Description
24 January, 2023	Various	Changed CXM and DXM2 to CXM2 and DXM2.5
8 July, 2021	All	All
25 July, 2017	Page 7	Hanger and mounting details
16 May, 2017	Page 39	Added Maximum Altitude and changed limits description on operating limits tables
23 October, 2015	Page 4	Added a safety warning
18 August, 2015	All	First Published





ClimateMaster works continually to improve its products. As a result, the design and specifications of each product at the time for order may be changed without notice and may not be as described herein. Please contact ClimateMaster's Customer Service Department at +1-405-745-6000 for specific information on the current design and specifications. Statements and other information contained herein are not express warranties and do not form the basis of any bargain between the parties, but are merely ClimateMaster's opinion or commendation of its products.

ClimateMaster is a proud supporter of the Geothermal Exchange Organization - GEO. For more information visit geoexchange.org.

© ClimateMaster, Inc. 2009